


# Do not disturb system introduction



① When indoor switch of "DND" is off, outdoor indicator of "DND" shows no light. With this working condition, push the doorbell switch of outdoor indicator, buzzer indoor will make a sound "Ding Dong".

② When indoor switch of "DND" is on, outdoor indicator of "DND" shows red light. With this working condition, push the doorbell switch of outdoor indicator, buzzer indoor **can't** make a sound "Ding Dong".

