

Switch & Socket
www.artdna-global.com

86 STYLE CATALOGUE

**ART
DNA**

International Switch Expert



ZHONGSHAN GAMDER ELECTRIC APPLIANCE CO.,LTD

Addr: No.8-1 Middle of Industry Avenue, XiaoLan Town, ZhongShan,GuangDong, China.

Tel: 0086 760 2255 1677

Fax: 0086 760 2255 1960

E-mail: artdnasales_01@gamder.cn

www.artdna-global.com

ARTDNA Switches & Sockets



E-Catalogue

86 STYLE CATALOGUE

ARTDNA CONTENTS

About ARTDNA	3
Marketing	5
Qualification and Certificates	7
ARTDNA Concept	8
Products Structure	9
V23 series	11
V12 series	17
A77 series	23
A69 series	29
A66 series	36
A68 series	43
A38 series	49
D3 series	55
A63 series	61
E3 series	67
B3 series	74



About ARTDNA

The ARTDNA brand was founded in 2012 and is one of the two major brands of Zhongshan Gamder Electric Appliance Co., Ltd. Since its establishment, the ARTDNA brand has a strong sense of modernity and an international mission. Through unremitting efforts, in 2014, ARTDNA created a new category representing one of the development directions of electrical products: CONJOIN SWITCHES.

In 2019, with the rise of intelligent development of electrical products, ARTDNA began to deploy intelligent control, and promote the "intelligent optoelectronic integration" project according to the development and demand of the market.

In terms of intelligent control, ARTDNA cooperates to develop and produce a variety of intelligent switches, intelligent dimming, intelligent touch screens, gateways and intelligent lighting drivers, and has established in-depth cooperation with many intelligent ecological enterprises in the industry, and thus won the "Guangdong Province Famous Brand Product" and other honors.



Market Internationalization



- ARTDNA Showroom
Malaysia




- ARTDNA Showroom
Thailand



- ARTDNA Showroom Vietnam



- ARTDNA Showroom
Iraq



- Select 2022 Bangkok



- Canton Fair Guangzhou



- Lighting Fair Hongkong



- MEE Dubai



- Hilton Garden Inn Thailand



- Moty Hotel Malaysia



- Pistachio Hotel Vietnam



- MBR City U.A.E

Qualification And Certificates


The ARTDNA trademark has been registered in many countries around the world. Some of the national registration certificates show:



• ISO9001 ISO 14001 Certification



• SQM Certificate



• ASTA Certificate



• CE Certification



• CB Certificate



• TIS Certificate



• Invention Patent




• Practical Patent




• Design Patent



Products Structure



Switch



Socket

V23 SERIES

- Frameless Large Panel Design
- High Current Load Design For Larger LED Loading
- Large Size Sliding Terminal For Easier Wiring
- Multiple materials optional
- Switch with LED Indicator



V23-K01A V23-K01B
10AX 1 Gang Switch
PACK: 80pcs 1



V23-K02A V23-K02B
10AX 2 Gang Switch
PACK: 80pcs 2



V23-K03A V23-K03B
10AX 3 Gang Switch
PACK: 80pcs 3



V23-K04A V23-K04B
10AX 4 Gang Switch
PACK: 80pcs 4



V23-K16
10A Doorbell Switch
PACK: 80pcs 5



V23-K19
10AX 1 Gang Intermediate Switch
PACK: 80pcs 6



V23-K20
10AX 2 Gang Intermediate Switch
PACK: 80pcs 7



V23-BK01A V23-BK01B
10AX 1 Gang Full-Flat with LED Indicator Switch
PACK: 80pcs 8



V23-BK02A V23-BK02B
10AX 2 Gang Full-Flat with LED Indicator Switch
PACK: 80pcs 9



V23-BK03A V23-BK03B
10AX 3 Gang Full-Flat with LED Indicator Switch
PACK: 80pcs 10



V23-BK04A V23-BK04B
10AX 4 Gang Full-Flat with LED Indicator Switch
PACK: 80pcs 11



V23-K77
10AX 1 Gang Full-Flat with LED Indicator Intermediate Switch
PACK: 80pcs 12



V23-P01
Single Blank Plate
PACK: 200pcs 13



V23-K45 V23-K46
5A/13A Switched Fused Connection Unit with Neon
PACK: 80pcs 14



V23-K30
20A Double Pole Switch with Neon
PACK: 80pcs 15



V23-K50-2
45A Double Pole Switch with LED Indicator
PACK: 80pcs 16



V23-C11
13A BS Socket
PACK: 80pcs 17



V23-C29
13A BS Socket with Switch
PACK: 80pcs 18



V23-C12
13A Single Switched Socket with Neon
PACK: 80pcs 19



V23-C31
13A BS Socket with DP Switch
PACK: 80pcs 20



V23-C32
13A Single Socket with DP Switch
& Neon
PACK: 80pcs 21



V23-C29E16
13A BS Switched Socket with
2.1A USB Charger
PACK: 60pcs 22



V23-C31E16
13A Double Pole BS Switched
Socket with 2.1A USB Charger
PACK: 60pcs 23



V23-JAC28
16A 1 Gang Euro-American
Socket with Switch
PACK: 80pcs 24



V23-E24-2
3.1A Double USB Charger
PACK: 60pcs 41



V23-E31
20W Type A+C USB Charger
PACK: 60pcs 42



V23-E33
65W Type A+C USB Charger
PACK: 60pcs 43



V23-P37
45A Flex Outlet
PACK: 60pcs 44



V23-C28K
16A Switched Euro & American
Socket
PACK: 80pcs 25



V23-C28E24
16A Euro & American Socket
with 2 Ports USB Charge
PACK: 60pcs 26



V23-C28E32
16A Euro & American Socket
with Type A+C USB Charge
PACK: 60pcs 27



V23-C42
16A Double Euro & American
Socket
PACK: 80pcs 28



V23-P38
25A Flex Outlet
PACK: 80pcs 45



V23-E01
Telephone Socket
PACK: 80pcs 46



V23-E02
Computer Socket(CAT.6)
PACK: 80pcs 47



V23-E03
Single TV Socket
PACK: 80pcs 48



V23-C18
16A 2P + E German Socket
PACK: 80pcs 29



V23-C22
16A 2P+E French Socket
PACK: 80pcs 30



V23-C23
16A 2P European Socket
PACK: 80pcs 31



V23-C17
15A 3 Round Pin Socket
with Switch
PACK: 80pcs 32



V23-2E01 V23-2E02
Double Telephone Socket
Double Computer Socket (CAT.6)
PACK: 80pcs 49



V23-E0102
Telephone & Computer Socket
(CAT.6)
PACK: 80pcs 50



V23-2E03
Double TV Socket
PACK: 80pcs 51



V23-E06
Single Satellite Socket
PACK: 80pcs 52



V23-C38
15A 3 Round Pin Switched Socket
with LED Indicator
PACK: 80pcs 33



V23-C06
16A 2 Pin & 3 Pin Universal Socket
PACK: 80pcs 34



V23-C36
16A 3 Pin Universal Socket
with Switch
PACK: 80pcs 35



V23-C37
16A 3 Pin Universal Switched Socket
with LED Indicator
PACK: 80pcs 36



V23-E0608
TV & Satellite Socket
PACK: 80pcs 53



V23-E0103 V23-E0203
Telephone & TV Socket
Computer & TV Socket (CAT.6)
PACK: 80pcs 54



V23-E0206
Computer & Satellite Socket(CAT6)
PACK: 80pcs 55



V23-2E07
2 Gang Speaker Outlet
PACK: 80pcs 56



V23-C45
16A Switched Universal Socket
with Night Light
PACK: 80pcs 37



V23-C06E29
2 Pin & 3 Pin Universal Socket
with 2.1A Double USB Charger
PACK: 60pcs 38



V23-C06E24
2 Pin & 3 Pin Universal Socket
with 3.4A Double USB Charger
PACK: 60pcs 39



V23-C06E32
2 Pin & 3 Pin Universal Socket
with Type A+C USB Charger
PACK: 60pcs 40



V23-K22 V23-K24
Background/General Speaker
Voice Dimmer Switch
PACK: 60pcs 57



V23-K09 V23-K10
300W Light Dimmer Switch
630W Light Dimmer Switch
PACK: 60pcs 58



V23-K86
1000W Two Way Push Dimmer
Switch
PACK: 60pcs 59



V23-2K100
Twin 100W LED Dimmer Switch
PACK: 60pcs 60



V23-K11
300W Fan Dimmer Switch

PACK: 60pcs 61



V23-K88
300W Two Way Push Fan Dimmer Switch

PACK: 60pcs 62



V23-K93
100W Step Fan Dimmer Switch

PACK: 40pcs 63



V23-K12
Air Control Dimmer Switch

PACK: 60pcs 64



V23-K97
"DO NOT DISTURB" & "MAKE UP ROOM" Switch

PACK: 80pcs 81



V23-K98
"DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Switch

PACK: 80pcs 82



V23-C34
10VA 115V~ / 10A 230V~ Shaver Socket

PACK: 16pcs 83



V23-C08
3X6 Shaver Socket

PACK: 10pcs 84



V23-K01BK09
300W Light Dimmer With Two Way Rocker Switch

PACK: 60pcs 65



V23-K01BK11
300W Fan Dimmer With Two Way Rocker Switch

PACK: 60pcs 66



V23-K25
Acoustooptic Controlled Switch with Time Delay

PACK: 80pcs 67



V23-K26
Touch Switch with Time Delay

PACK: 80pcs 68



V23-C13
13A Twin BS Socket

PACK: 50pcs 85



V23-C30
13A Twin BS Socket with Switch

PACK: 50pcs 86



V23-C14
13A Twin BS Socket with Switch & LED Indicator

PACK: 50pcs 87



V23-C39
13A Twin BS Socket with DP Switch

PACK: 50pcs 88



V23-K23
PIR Switch

PACK: 60pcs 69



V23-K85
PIR Floor Light

PACK: 80pcs 70



V23-K36
LED Foot Light

PACK: 80pcs 71



V23-K37
1W Buzzer

PACK: 80pcs 72



V23-C40
13A Twin BS Socket with DP Switch & LED Indicator

PACK: 50pcs 89



V23-C30E24
13A Twin Switched Socket with 2 Ports USB Charger

PACK: 40pcs 90



V23-C14E24
13A Twin Switched Socket with 2 Ports USB Charger & Neon

PACK: 40pcs 91



V23-C39E24
13A Twin DP Switched Socket with 2 Ports USB Charger

PACK: 40pcs 92



V23-K31
3A Alarm Switch

PACK: 80pcs 73



V23-K17
2A Bell Switch with "DO NOT DISTURB" Indicator

PACK: 80pcs 74



V23-K18
2A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" Indicator

PACK: 80pcs 75



V23-K21
2A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Indicator

PACK: 80pcs 76



V23-C40E24
13A Twin DP Switched Socket with 2 Ports USB Charger & Neon

PACK: 40pcs 93



V23-C43
16A Twin Universal Switched Socket

PACK: 50pcs 94



V23-C43E24
16A Twin Universal Switched Socket with 2 Ports USB Charger

PACK: 40pcs 95



V23-C44
16A Twin Universal Switched Socket with Neon

PACK: 50pcs 96



V23-K15
16A Key Card Switch

PACK: 60pcs 77



V23-K43
16A Low Frequency Key Card Switch

PACK: 60pcs 78



V23-K44
16A High Frequency Key Card Switch

PACK: 60pcs 79



V23-K96
"DO NOT DISTURB" Switch

PACK: 80pcs 80



V23-C44E24
16A Twin Universal Switched Socket with 2 Ports USB Charger & Neon

PACK: 40pcs 97



V23-C26
45A Cooker Unit

PACK: 50pcs 98



V23-K90
147 45A DP Switch

PACK: 50pcs 99



V23-P28
Double Blank Plate

PACK: 160pcs 100

V12 SERIES

- Colorful Metal Stamping Logo
- Crystal Texture Without Borders Large Panel
- High Current Load Design For Larger LED Loading
- Large Size Sliding Terminal For Easier Wiring



V12-K01A V12-K01B
10AX 1 Gang Switch
PACK: 80pcs 1



V12-K02A V12-K02B
10AX 2 Gang Switch
PACK: 80pcs 2



V12-K03A V12-K03B
10AX 3 Gang Switch
PACK: 80pcs 3



V12-K04A V12-K04B
10AX 4 Gang Switch
PACK: 80pcs 4



V8 -K16
10A Doorbell Switch
PACK: 80pcs 5



V12-K19
10AX 1 Gang Intermediate Switch
PACK: 80pcs 6



V12-K20
10AX 2 Gang Intermediate Switch
PACK: 80pcs 7



V12-P01
Single Blank Plate
PACK: 200pcs 8



V12-K45 V12-K46
5A/13A Switched Fused Connection Unit with Neon
PACK: 80pcs 9



V12-K30
20A Double Pole Switch with Neon
PACK: 80pcs 10



V12-K50
45A Double Pole Switch with LED Indicator
PACK: 80pcs 11



V12-C11
13A BS Socket
PACK: 80pcs 12



V12-C29-3
13A BS Socket with Switch
PACK: 80pcs 13



V12-C12-3
13A Single Switched Socket with Neon
PACK: 80pcs 14



V12-C31
13A BS Socket with DP Switch
PACK: 80pcs 15



V12-C32
13A Single Socket with DP Switch & Neon
PACK: 80pcs 16



V12-C29E16
13A BS Switched Socket with 2.1A USB Charger
PACK: 60pcs 17



V12-C31E16
13A Double Pole BS Switched Socket with 2.1A USB Charger
PACK: 60pcs 18



V12-JAC28
16A 1 Gang Euro-American Socket with Switch
PACK: 80pcs 19



V12-C28K
16A Switched Euro & American Socket
PACK: 80pcs 20



V12-C28E24
16A Euro & American Socket
with 2 Ports USB Charge
PACK: 60pcs 21



V12-C28E32
16A Euro & American Socket
with Type A+C USB Charge
PACK: 60pcs 22



V12-C18
16A 2P + E German Socket
PACK: 80pcs 23



V12-C22
16A 2P+E French Socket
PACK: 80pcs 24



V12-E02
Computer Socket(CAT.6)
PACK: 80pcs 41



V12-E03
Single TV Socket
PACK: 80pcs 42



V12-2E01 V12-2E02
Double Telephone Socket
Double Computer Socket (CAT.6)
PACK: 80pcs 43



V12-E0102
Telephone & Computer Socket
(CAT.6)
PACK: 80pcs 44



V12-C23
16A 2P European Socket
PACK: 80pcs 25



V12-C17
15A 3 Round Pin Switched
Socket
PACK: 80pcs 26



V12-C38
15A 3 Round Pin Switched Socket
with LED Indicator
PACK: 80pcs 27



V12-C06
16A 2 Pin & 3 Pin Universal Socket
PACK: 80pcs 28



V12-2E03
Double TV Socket
PACK: 80pcs 45



V12-E06
Single Satellite Socket
PACK: 80pcs 46



V12-E0608
TV & Satellite Socket
PACK: 80pcs 47



V12-E0103 V12-E0203
Telephone & TV Socket
Computer & TV Socket (CAT.6)
PACK: 80pcs 48



V12-C36
16A 3 Pin Universal Socket
with Switch
PACK: 80pcs 29



V12-C37
16A 3 Pin Universal Switched Socket
with LED Indicator
PACK: 80pcs 30



V12-C45
16A Switched Universal Socket
with Night Light
PACK: 80pcs 31



V12-C06E29
2 Pin & 3 Pin Universal Socket
with 2.1A Double USB Charger
PACK: 60pcs 32



V12-E0206
Computer & Satellite Socket(CAT6)
PACK: 80pcs 49



V12-2E07
2 Gang Speaker Outlet
PACK: 80pcs 50



V12-K22 V12-K24
Background/General Speaker
Voice Dimmer Switch
PACK: 60pcs 51



V12-K09 V12-K10
300W Light Dimmer Switch
630W Light Dimmer Switch
PACK: 60pcs 52



V12-C06E24
2 Pin & 3 Pin Universal Socket
with 3.4A Double USB Charger
PACK: 60pcs 33



V12-C06E32
2 Pin & 3 Pin Universal Socket
with Type A+C USB Charger
PACK: 60pcs 34



V12-E24-2
3.1A Double USB Charger
PACK: 60pcs 35



V12-E31
20W Type A+C USB Charger
PACK: 60pcs 36



V12-K86
1000W Two Way Push Dimmer
Switch
PACK: 60pcs 53



V12-2K100
Twin 100W LED Dimmer Switch
PACK: 60pcs 54



V12-K11
300W Fan Dimmer Switch
PACK: 60pcs 55



V12-K88
300W Two Way Push Fan
Dimmer Switch
PACK: 60pcs 56



V12-E33
65W Type A+C USB Charger
PACK: 60pcs 37



V12-P37
45A Flex Outlet
PACK: 60pcs 38



V12-P38
25A Flex Outlet
PACK: 80pcs 39



V12-E01
Telephone Socket
PACK: 80pcs 40



V12-K93
100W Step Fan Dimmer Switch
PACK: 40pcs 57



V12-K12
Air Control Dimmer Switch
PACK: 60pcs 58



V12-K01BK09
300W Light Dimmer With
Two Way Rocker Switch
PACK: 60pcs 59



V12-K01BK11
300W Fan Dimmer With Two
Way Rocker Switch
PACK: 60pcs 60



V12-K25
Acoustooptic Controlled Switch
with Time Delay
PACK: 80pcs 61



V12-K26
Touch Switch with Time Delay
PACK: 80pcs 62



V12-K23
PIR Switch
PACK: 60pcs 63



V12-K85
PIR Floor Light
PACK: 60pcs 64



V12-C14
13A Twin BS Socket with
Switch & LED Indicator
PACK: 50pcs 81



V12-C39
13A Twin BS Socket with DP Switch
PACK: 50pcs 82



V12-C40
13A Twin BS Socket with DP
Switch & LED Indicator
PACK: 50pcs 83



V12-C30E24
13A Twin Switched Socket with
2 Ports USB Charger
PACK: 40pcs 84



V12-K36
LED Foot Light
PACK: 80pcs 65



V12-K37
1W Buzzer
PACK: 80pcs 66



V12-K31
3A Alarm Switch
PACK: 80pcs 67



V12-K17
2A Bell Swith with "DO NOT
DISTURB" Indicator
PACK: 80pcs 68



V12-C14E24
13A Twin Switched Socket with
2 Ports USB Charger & Neon
PACK: 40pcs 85



V12-C39E24
13A Twin DP Switched Socket with
2 Ports USB Charger
PACK: 40pcs 86



V12-C40E24
13A Twin DP Switched Socket with
2 Ports USB Charger & Neon
PACK: 40pcs 87



V12-C43
16A Twin Universal Switched Socket
PACK: 50pcs 88



V12-K18
2A Bell Swith with "DO NOT DISTURB"
& "MAKE UP ROOM" Indicator
PACK: 80pcs 69



V12-K21
2A Bell Swith with "DO NOT DISTURB"&
"MAKE UP ROOM" & "PLEASE WAIT"
Indicator
PACK: 80pcs 70



V12-K15
16A Key Card Switch
PACK: 60pcs 71



V12-K43
16A Low Frequency
Key Card Switch
PACK: 60pcs 72



V12-C43E24
16A Twin Universal Switched Socket
with 2 Ports USB Charger
PACK: 40pcs 89



V12-C44
16A Twin Universal Switched Socket
with Neon
PACK: 50pcs 90



V12-C44E24
16A Twin Universal Switched Socket
with 2 Ports USB Charger & Neon
PACK: 40pcs 91



V12-C26
45A Cooker Unit
PACK: 50pcs 92



V12-K44
16A High Frequency
Key Card Switch
PACK: 60pcs 73



V12-K96
"DO NOT DISTURB" Switch
PACK: 80pcs 74



V12-K97
"DO NOT DISTURB" & "MAKE
UP ROOM" Switch
PACK: 80pcs 75



V12-K98
"DO NOT DISTURB" & "MAKE UP
ROOM" & "PLEASE WAIT" Switch
PACK: 80pcs 76



V12-K90
147 45A DP Switch
PACK: 50pcs 93



V12-P28
Double Blank Plate
PACK: 160pcs 94



V12-C34
10VA 115V~ / 10A 250V~
Shaver Socket
PACK: 16pcs 77



V12-C08
3X6 Shaver Socket
PACK: 10pcs 78



V12-C13
13A Twin BS Socket
PACK: 50pcs 79



V12-C30
13A Twin BS Socket with
Switch
PACK: 50pcs 80

A77 SERIES

- Modular products, freely assembled
- A variety of color modules, a variety of materials frame
- Purely flat switch with LED indicator and rocker switch optional



Multicolor Frames-1

Thin Aluminum Series

	A77-P24	86 Frame	PACK: 200 pcs
	A77-P19	286 Frame	PACK: 120 pcs
	A77-P20	386 Frame	PACK: 60 pcs
	A77-P21	486 Frame	PACK: 50 pcs
	A77-P29	586 Frame	PACK: 40 pcs
	A77-P23	2 Gang Frame	PACK: 100 pcs

Space Grey Aluminum Series

	A78-P24A	86 Frame	PACK: 200 pcs
	A78-P19A	286 Frame	PACK: 100 pcs
	A78-P20A	386 Frame	PACK: 60 pcs
	A78-P21A	486 Frame	PACK: 50 pcs
	A78-P29A	586 Frame	PACK: 40 pcs
	A78-P23A	2 Gang Frame	PACK: 100 pcs

Rose Golden Aluminum Series

	A78-P24B	86 Frame	PACK: 200 pcs
	A78-P19B	286 Frame	PACK: 100 pcs
	A78-P20B	386 Frame	PACK: 60 pcs
	A78-P21B	486 Frame	PACK: 50 pcs
	A78-P29B	586 Frame	PACK: 40 pcs
	A78-P23B	2 Gang Frame	PACK: 100 pcs

Champagne Golden Aluminum Series

	A78-P24A	86 Frame	PACK: 200 pcs
	A78-P19A	286 Frame	PACK: 100 pcs
	A78-P20A	386 Frame	PACK: 60 pcs
	A78-P21A	486 Frame	PACK: 50 pcs
	A78-P29A	586 Frame	PACK: 40 pcs
	A78-P23A	2 Gang Frame	PACK: 100 pcs

White Crystal Glass Series

	A78-P24F	86 Frame	PACK: 200 pcs
	A78-P19F	286 Frame	PACK: 100 pcs
	A78-P20F	386 Frame	PACK: 60 pcs
	A78-P21F	486 Frame	PACK: 50 pcs
	A78-P29F	586 Frame	PACK: 40 pcs
	A78-P23F	2 Gang Frame	PACK: 100 pcs

Black Crystal Glass Series

	A78-P24F	86 Frame	PACK: 200 pcs
	A78-P19F	286 Frame	PACK: 100 pcs
	A78-P20F	386 Frame	PACK: 60 pcs
	A78-P21F	486 Frame	PACK: 50 pcs
	A78-P29F	586 Frame	PACK: 40 pcs
	A78-P23F	2 Gang Frame	PACK: 100 pcs

Multicolor Frames-2

Brushed Stainless Series

	A77-P24A	86 Frame	PACK: 200 pcs
	A77-P19A	286 Frame	PACK: 120 pcs
	A77-P20A	386 Frame	PACK: 60 pcs
	A77-P21A	486 Frame	PACK: 50 pcs
	A77-P29A	586 Frame	PACK: 40 pcs

Mirror Stainless Series

	A77-P24B	86 Frame	PACK: 200 pcs
	A77-P19B	286 Frame	PACK: 120 pcs
	A77-P20B	386 Frame	PACK: 60 pcs
	A77-P21B	486 Frame	PACK: 50 pcs
	A77-P29B	586 Frame	PACK: 40 pcs

Plastic Champagne Series

	A77-P24D	86 Frame	PACK: 320 pcs
	A77-P19D	286 Frame	PACK: 160 pcs
	A77-P20D	386 Frame	PACK: 72 pcs
	A77-P21D	486 Frame	PACK: 60 pcs
	A77-P29D	586 Frame	PACK: 48 pcs

Plastic Silver Series

	A77-P24D	86 Frame	PACK: 320 pcs
	A77-P19D	286 Frame	PACK: 160 pcs
	A77-P20D	386 Frame	PACK: 72 pcs
	A77-P21D	486 Frame	PACK: 60 pcs
	A77-P29D	586 Frame	PACK: 48 pcs

Modules


				
A77-K01A-2 A77-K01B-2 10AX 1 Gang Switch Rocker PACK: 160pcs	A77-K02A-2 A77-K02B-2 10AX 2 Gang Switch Rocker PACK: 160pcs	A77-K03A-2 A77-K03B-2 10AX 3 Gang Switch Rocker PACK: 160pcs	A77-K04A-2 A77-K04B-2 10AX 4 Gang Switch Rocker PACK: 160pcs	A77-K16 10A Doorbell Switch PACK:160 pcs
1	2	3	4	5

				
A77-K1A A77-K1B 10AX 1 Gang Full-Flat Switch with LED Indicator PACK:160 pcs	A77-K2A A77-K2B 10AX 2 Gang Full-Flat Switch with LED Indicator PACK: 160pcs	A77-K3A A77-K3B 10AX 3 Gang Full-Flat Switch with LED Indicator PACK: 160pcs	A77-K16 10A 1 Gang Retractive Switch PACK:160 pcs	A77-K28 10A 2 Gang Retractive Switch PACK:160 pcs
6	7	8	9	10

				
A77-K51 DC 12V 1 Gang Switch with LED Indicator PACK:160 pcs	A77-K52 DC 12V 2 Gang Switch with LED Indicator PACK: 160 pcs	A77-K53 DC 12V 3 Gang Switch with LED Indicator PACK:160 pcs	A77-K19-2 10AX 1 Gang Intermediate Switch Module PACK:160 pcs	A77-K20-2 10AX 2 Gang Intermediate Switch Module PACK:160 pcs
11	12	13	14	15

				
A77-P01 Single Blank PACK:384 pcs	A77-K45 A77-K46 5A/13A Switched Fused Connection Unit with Neon PACK:160 pcs	A77-K30 20A Double Pole Switch with Neon PACK:160 pcs	A77-K50-2 45A Double Pole Switch with LED Indicator PACK:160 pcs	A77-C11 13A BS Socket PACK: 160pcs
16	17	18	19	20

				
A77-C29-3 13A BS Socket with Switch PACK:160 pcs	A77-C12-3 BS Socket with Switch & LED Indicator PACK:160 pcs	A77-C31-2 13A Single Socket with DP Switch PACK: 160pcs	A77-C32-2 13A Single Socket with DP Switch & Neon PACK: 160pcs	A77-C29E16 13A BS Switched Socket with 2.1A USB Charger PACK: 96 pcs
21	22	23	24	25

				
A77-C31E16 13A Double Pole BS Switched Socket with 2.1A USB Charger PACK: 96 pcs	A77-JAC28 16A 1 Gang Euro-American Socket with Switch PACK: 160pcs	A77-C28K 16A Switched Euro & American Socket Module PACK:160 pcs	A77-C28E24 16A Euro & American Socket with 2 Ports USB Charge Module PACK: 96 pcs	A77-C28E32 16A Euro & American Socket with Type A+C USB Charge Module PACK: 96 pcs
26	27	28	29	30

				
A77-C42 16A Double Euro & American Socket Module PACK: 80 pcs	A77-C18-2 16A 2P + E German Socket PACK: 96 pcs	A77-C22-2 16A 2P+E French Socket PACK:160 pcs	A77-C23-2 16A 2P European Socket PACK:160 pcs	A77-C17-2 15A 3 Round Pin Socket With Switch PACK:160 pcs
31	32	33	34	35

				
A77-C38 15A 3 Round Pin Switched Socket with LED Indicator PACK:160 pcs	A77-C06 16A 2 Pin & 3 Pin Universal Socket PACK:160 pcs	A77-C36 16A 3 Pin Universal Socket with Switch PACK:160 pcs	A77-C37 16A 3 Pin Universal Switched Socket with LED Indicator Module PACK:160 pcs	A77-C45 16A Switched Universal Socket with Night Light PACK: 96 pcs
36	37	38	39	40

				
A77-C06E29 2 Pin & 3 Pin Universal Socket with 2.1A Double USB Charger PACK:96 pcs	A77-C06E24 16A 2 Pin & 3 Pin Universal Socket with 3.4A Double USB Charger PACK:96 pcs	A77-C06E32 2 Pin & 3 Pin Universal Socket with Type A+C USB Charger Module PACK: 96 pcs	A77-E24-2 3.1A Double USB Charger Module PACK: 96 pcs	A77-E31 20W Type A+C USB Charger PACK: 96 pcs
41	42	43	44	45



A77-E33
65W Type A+C USB Charger
PACK: 96 pcs 46



A77-P37
45A Flex outlet
PACK: 96 pcs 47



A77-P38
25A Flex outlet
PACK:160 pcs 48



A77-E01
Single Telephone Socket
PACK:160 pcs 49



A77-E02
Single Computer Socket
PACK:160 pcs 50



A77-K37
1W Buzzer
PACK:160 pcs 76



A77-K31
3A Alarm Switch
PACK:160 pcs 77



A77-K17
2A Bell Swith with "DO NOT DISTURB" Indicator
PACK:160 pcs 78



A77-K18
2A Bell Swith with "DO NOT DISTURB" & "MAKE UP ROOM" Indicator
PACK:160 pcs 79



A77-K21
2A Bell Swith with "DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Indicator
PACK:160 pcs 80



A77-E03
Single TV Socket
PACK:160 pcs 51



A77-2E01
Double Telephone Socket
PACK:160 pcs 52



A77-2E02
Double Computer Socket
PACK:160 pcs 53



A77-E0102
Telephone & Computer Socket
PACK:160 pcs 54



A77-E06
Satellite Socket
PACK:160 pcs 55



A77-K15
16A KeyCard Switch
PACK:96 pcs 81



A77-K43
16A Low Frequency KeyCard Switch
PACK:96 pcs 82



A77-K44
16A High Frequency KeyCard Switch
PACK:96 pcs 83



A77-K96
"DO NOT DISTURB" Switch Module
PACK:160 pcs 84



A77-K97
"DO NOT DISTURB" & "MAKE UP ROOM" Switch Module
PACK:160 pcs 85



A77-E0608
TV & Satellite Socket
PACK:160 pcs 56



A77-E0103
Telephone & TV Socket
PACK:160 pcs 57



A77-E0203
Computer & TV Socket
PACK:160 pcs 58



A77-E0206
Computer & Satellite Socket Module
PACK:160 pcs 59



A77-2E07
2 Gang Speaker Outlet
PACK:160 pcs 60




A77-K98
"DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Switch Module
PACK:160 pcs 86



A77-C34
10VA 115V~ / 10A 230V~ Shaver Socket
PACK: 16 pcs 87



A77-C08
Shaver Socket
PACK: 10 pcs 88



A77-C13-2
13A Twin BS Socket
PACK: 50pcs 89



A77-C30-2
13A Twin BS Socket with Switch
PACK: 50pcs 90



A77-K22
Background/General Speaker Voice Dimmer Switch
PACK: 96 pcs 61



A77-K09
300W Light Dimmer
PACK: 96pcs 62



A77-K10
630W Light Dimmer
PACK: 96pcs 63



A77-K86
1000W 2 Way Light Dimmer Switch
PACK: 96 pcs 64



A77-2K100
Twin 100W LED Dimmer Switch
PACK: 96 pcs 65



A77-K11
300W Fan Dimmer Switch
PACK:96 pcs 66



A77-C14-2
13A Twin BS Socket with Switch & LED Indicator
PACK: 50pcs 91



A77-C39
13A Twin BS Socket with DP Switch
PACK: 50pcs 92



A77-C40
13A Twin BS Socket with DP Switch & LED Indicator
PACK: 50pcs 93



A77-C30E24
13A Twin Switched Socket with 2 Ports USB Charger
PACK: 40 pcs 94



A77-K88
300W Two Way Push Fan Dimmer Switch
PACK: 96pcs 67



A77-K93
100W Step Fan Dimmer Switch
PACK: 96 pcs 68



A77-K12
Air Control Dimmer Switch
PACK: 96 pcs 69



A77-K01BK09
300W Light Dimmer With Two Way Rocker Switch
PACK: 96 pcs 70



A77-K01BK11
300W Fan Dimmer With Two Way Rocker Switch
PACK: 96 pcs 71



A77-C39E24
13A Twin DP Switched Socket with 2 Ports USB Charger
PACK: 40 pcs 96



A77-C40E24
13A Twin DP Switched Socket with 2 Ports USB Charger & Neon
PACK: 40 pcs 97



A77-C43
16A Twin Universal Switched Socket
PACK: 50 pcs 98



A77-C43E24
16A Twin Universal Switched Socket with 2 Ports USB Charger
PACK: 40 pcs 99



A77-C44
16A Twin Universal Switched Socket with Neon
PACK: 50 pcs 100



A77-K25
45-100W Voice Activated & Light Sensor Switch with Time Delay
PACK:160 pcs 72



A77-K26
Touch Switch with Time Delay
PACK:160 pcs 73



A77-K23
65-100W PIR Switch
PACK:96 pcs 74



A77-K85
PIR Foot Light
PACK:160 pcs 75



A77-K36
0.7W LED Footlight
PACK:160 pcs 76



A77-C44E24
16A Twin Universal Switched Socket with 2 Ports USB Charger & Neon
PACK: 40 pcs 101



A77-C26
45A Cooker Unit
PACK: 50pcs 102



A77-K90
147 45A DP Switch
PACK: 50 pcs 103



A77-P28
Double Blank Module
PACK: 400pcs 104

A69 SERIES

- 1.0mm Brushed metal panel
- 304 stainless steel
- Purely flat switch with LED indicator and rocker switch optional



A69-BK01A A69-BK01B
16AX 1 Gang Switch Rocker

PACK: 80pcs 1



A69-BK02A A69-BK02B
16AX 2 Gang Switch Rocker

PACK: 80pcs 2



A69-BK03A A69-BK03B
16AX 3 Gang Switch Rocker

PACK: 80pcs 3



A69-BK04A A69-BK04B
10AX 4 Gang Switch Rocker

PACK: 80pcs 4



E9-K16
16A Doorbell Switch

PACK: 80pcs 5



A69-BK19
10AX 1 Gang Intermediate Switch

PACK: 80pcs 6



A69-BK20
10AX 2 Gang Intermediate Switch

PACK: 80pcs 7



A69-BK1A A69-BK1B
10AX 1 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 8



A69-BK2A A69-BK2B
10AX 2 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 9



A69-BK3A A69-BK3B
10AX 3 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 10



A69-BK4A A69-BK4B
10AX 4 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 11



K9-BK1A K9-BK1B
10AX 1 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 12



K9-BK2A K9-BK2B
10AX 2 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 13



K9-BK3A K9-BK3B
10AX 3 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 14



K9-BK4A K9-BK4B
10AX 4 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 15



K9-K77
10AX 1 Gang Intermediate Full-Flat Switch with LED Indicator

PACK: 80pcs 16



A69-P01
Single Blank Plate

PACK: 200pcs 17



A69-K45/K46
5A/13A Switched Fused Connection Unit with Neon

PACK: 80pcs 18



A69-K30
20A Double Pole Switch with Neon

PACK: 80pcs 19



A69-K50-2
45A Double Pole Switch with LED Indicator

PACK: 80pcs 20



A69-C11
13A BS Socket
PACK: 80pcs 21



A69-C29
13A BS Socket with Switch
PACK: 80pcs 22



A69-C12
13A BS Socket with Switch & Neon
PACK: 80pcs 23



A69-C29-3
13A Single Switch Socket
PACK: 80pcs 24



A69-C36
16A 3 Pin Universal Socket with Switch
PACK: 80pcs 41



A69-C37
16A 3 Pin Universal Switched Socket with LED Indicator Module
PACK: 80pcs 42



A69-C45
16A Switched Universal Socket with Night Light
PACK: 80pcs 43



A69-C06E29
2 Pin & 3 Pin Universal Socket with 2.1A Double USB Charger
PACK: 60pcs 44



A69-C12-3
13A Single Switch Socket with Neon
PACK: 80pcs 25



A69-C31-2
13A BS Socket with DP Switch
PACK: 80pcs 26



A69-C32-2
13A BS Socket with DP Switch & LED Indicator
PACK: 80pcs 27



A69-C29E16
13A BS Switched Socket with 2.1A USB Charger
PACK: 60pcs 28



A69-C06E24
16A 2 Pin & 3 Pin Universal Socket with 3.4A Double USB Charger
PACK: 60pcs 45



A66-C06E32
2 Pin & 3 Pin Universal Socket with Type A+C USB Charger
PACK: 60pcs 46



A69-E24-2
3.1A Double USB Charger
PACK: 60pcs 47



A69-E31
20W Type A+C USB Charger
PACK: 60pcs 48



A69-C31E16
13A Double Pole BS Switched Socket with 2.1A USB Charger
PACK: 60pcs 29



A69-JAC28
16A 1 Gang Euro-American Socket with Switch
PACK: 80pcs 30



A69-C28K
16A Switched Euro & American Socket
PACK: 80pcs 31



A69-C28E24
16A Euro & American Socket with 2 Ports USB Charge
PACK: 60pcs 32



A69-E33
65W Type A+C USB Charger
PACK: 60pcs 49



A69-P37
45A Flex Outlet
PACK: 60pcs 50




A69-P38
25A Flex Outlet
PACK: 80pcs 51



A69-E01
Single Telephone Socket
PACK: 80pcs 52



A69-C28E32
16A Euro & American Socket with Type A+C USB Charge
PACK: 60pcs 33



A69-C42
16A Double Euro & American Socket
PACK: 80pcs 34




A69-C18-2
16A 2P+E German socket
PACK: 80pcs 35



A69-C22-2
16A 2P+E French socket
PACK: 80pcs 36



A69-E02
Single Computer Socket
PACK: 80pcs 53



A69-E03
Single TV Socket
PACK: 80pcs 54



A69-2E01
Double Telephone Socket
PACK: 80pcs 55



A69-2E02
Double Computer Socket (CAT.6)
PACK: 80pcs 56



A69-C23-2
16A 2P European Socket
PACK: 80pcs 37




A69-C17-2
15A 3 Round Pin Socket with Switch
PACK: 80pcs 38




A69-C38
15A 3 Round Pin Switched Socket with LED Indicator
PACK: 80pcs 39



A69-C06
16A 2 Pin & 3 Pin Universal Socket
PACK: 80pcs 40



A69-E0102
Telephone & Computer Socket (CAT.6)
PACK: 80pcs 57



A69-2E03
Double TV Socket
PACK: 80pcs 58



A69-E06
Single Satellite Socket
PACK: 80pcs 59



A69-E0608
TV & Satellite Socket
PACK: 80pcs 60



A69-E0103
Telephone &TV Socket

PACK: 80pcs 61



A69-E0203
Computer & TV Socket (CAT.6)

PACK: 80pcs 62



A69-E0206
Computer & Satellite Socket
Computer & Satellite Socket(CAT6)

PACK: 80pcs 63



A69-2E07
2 Gang Speaker Outlet

PACK: 80pcs 64



A69-K37
1W Buzzer

PACK: 80pcs 81



A69-K31
3A Alarm Switch

PACK: 80pcs 82



A69-K17
4A Bell Switch with
"DO NOT DISTURB" Indicator

PACK: 80pcs 83



A69-K18
4A Bell Switch with "DO NOT DISTURB"
& "MAKE UP ROOM" Indicator

PACK: 80pcs 84



A69-K22 **A69-K24**
Background/General Speaker
Voice Dimmer Switch

PACK: 60pcs 65



A69-K09
300W Light Dimmer Switch

PACK: 60pcs 66



A69-K10
630W Light Dimmer Switch

PACK: 60pcs 67



A69-K86
1000W Two Way Push Dimmer
Switch

PACK: 60pcs 68



A69-K21
4A Bell Switch with "DO NOT DISTURB" &
"MAKE UP ROOM" & "PLEASE WAIT"
Indicator

PACK: 80pcs 85



A69-K15
16A KeyCard Switch

PACK: 60pcs 86



A69-K43
16A Low Frequency Key Card
Switch

PACK: 60pcs 87



A69-K44
High Frequency Key Card
Switch

PACK: 60pcs 88



A69-2K100
Twin 100W LED Dimmer Switch

PACK: 60pcs 69



A69-K11
300W Fan Dimmer Switch

PACK: 60pcs 70



A69-K88
300W Two Way Push Fan
Dimmer Switch

PACK: 60pcs 71



A69-K93
100W 4 Steps Fan Dimmer Switch

PACK: 40pcs 72



A69-K96
"DO NOT DISTURB" Switch

PACK: 80pcs 89



A69-K97
"DO NOT DISTURB" &
"MAKE UP ROOM" Switch

PACK: 80pcs 90



A69-K98
"DO NOT DISTURB" & "MAKE UP
ROOM" & "PLEASE WAIT" Switch

PACK: 80pcs 91



A69-C34
10VA 115V~ / 10A 230V~
Shaver Socket

PACK:16 pcs 92



A69-K12
Air Control Dimmer Switch

PACK: 60pcs 73



A69-K01BK09
300W Light Dimmer With
Two Way Rocker Switch

PACK: 60pcs 74



A69-K01BK11
300W Fan Dimmer With
Two Way Rocker Switch

PACK: 60pcs 75



A69-K25
45-100W Voice Activated & Light
Sensor Switch with Time Delay

PACK: 80pcs 76



A69-C08
Shaver Socket

PACK: 10pcs 93



A69-C13
13A Twin BS Socket

PACK: 50pcs 94



A69-C30
13A Twin BS Socket with Switch

PACK: 50pcs 95



A69-C14
13A Twin BS Socket with
Switch & Neon

PACK: 50pcs 96



A69-K26
65-100W Touch Switch with
Time Delay

PACK: 80pcs 77



A69-K23
65-100W PIR Switch

PACK: 60pcs 78



A69-K85
PIR Floor Light

PACK: 80pcs 79



A69-K36
LED Foot Light

PACK: 60pcs 80



A69-C30-2
13A Twin BS Socket with Switch

PACK: 50pcs 97



A69-C14-2
13A Twin BS Socket with Switch
& LED Indicator

PACK: 50pcs 98



A69-C39
13A Twin BS Socket with DP
Switch

PACK: 50pcs 99



A69-C40
13A Twin BS Socket with DP Switch
& LED Indicator

PACK: 50pcs 100



A69-C30E24
13A Twin Switched Socket with
2 Ports USB Charger
PACK: 40pcs 101



A69-C14E24
13A Twin Switched Socket with
2 Ports USB Charger & Neon
PACK: 40pcs 102



A69-C39E24
13A Twin DP Switched Socket with
2 Ports USB Charger
PACK: 40pcs 103



A69-C40E24
13A Twin DP Switched Socket with
2 Ports USB Charger & Neon
PACK: 40pcs 104



A69-C43
16A Twin Universal Switched Socket
PACK: 50pcs 105



A69-C43E24
16A Twin Universal Switched Socket
with 2 Ports USB Charger
PACK: 40pcs 106



A69-C44
16A Twin Universal Switched Socket
with Neon
PACK: 50pcs 107



A69-C44E24
16A Twin Universal Switched Socket
with 2 Ports USB Charger & Neon
PACK: 40pcs 108



A69-C26
45A Cooker Unit
PACK: 50pcs 109



A69-K90
147 45A DP Switch
PACK: 50pcs 110



A69-K74A A69-K74B
10AX 147 4 Gang Switch
PACK: 50pcs 111



A69-K75A A69-K75B
10AX 147 5 Gang Switch
PACK: 50pcs 112



A69-P28
Double Blank Plate
PACK: 100pcs 113

A66 SERIES

- 0.4mm Brushed metal panel
- 304 stainless steel, gold aluminum optional
- Purely flat switch with LED indicator and rocker switch optional



Brushed Steel



Brushed Golden





A66-K01A A66-K01B
16AX 1 Gang Switch Rocker

PACK: 80pcs 1



A66-K02A A66-K02B
16AX 2 Gang Switch Rocker

PACK: 80pcs 2



A66-K03A A66-K03B
16AX 3 Gang Switch Rocker

PACK: 80pcs 3



A66-K04A A66-K04B
10AX 4 Gang Switch Rocker

PACK: 80pcs 4



A66-C29-3
13A Single Switch Socket

PACK: 80pcs 21



A66-C12-3
13A Single Switch Socket with Neon

PACK: 80pcs 22



A66-C31-2
13A BS Socket with DP Switch

PACK: 80pcs 23



A66-C32-2
13A BS Socket with DP Switch & LED Indicator

PACK: 80pcs 24



E9-K16
16A Doorbell Switch

PACK: 80pcs 5



E9-K16
16A 1 Gang Retractive Switch

PACK: 80pcs 6



A66-K19
10AX 1 Gang Intermediate Switch

PACK: 80pcs 7



A66-K20
10AX 2 Gang Intermediate Switch

PACK: 80pcs 8



A66-C29E16
13A BS Switched Socket with 2.1A USB Charger

PACK: 60pcs 25



A66-C31E16
13A Double Pole BS Switched Socket with 2.1A USB Charger

PACK: 60pcs 26



A66-JAC28
16A 1 Gang Euro-American Socket with Switch

PACK: 80pcs 27



A66-C28K
16A Switched Euro & American Socket

PACK: 80pcs 28



A66-BK1A A66-BK1B
10AX 1 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 9



A66-BK2A A66-BK2B
10AX 2 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 10



A66-BK3A A66-BK3B
10AX 3 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 11



A66-BK4A A66-BK4B
10AX 4 Gang Full-Flat Switch with LED Indicator

PACK: 80pcs 12



A66-C28E24
16A Euro & American Socket with 2 Ports USB Charge

PACK: 60pcs 29



A66-C28E32
16A Euro & American Socket with Type A+C USB Charge

PACK: 60pcs 30



A66-C18-2
16A 2P+E German socket

PACK: 80pcs 31



A66-C22-2
16A 2P+E French socket

PACK: 80pcs 32



A66-K77
10AX 1 Gang Intermediate Full-Flat Switch with LED Indicator

PACK: 80pcs 13



A66-P01
Single Blank Plate

PACK: 300pcs 14



A66-K45 A66-K46
5A / 13A Fuse Switch

PACK: 80pcs 15



A66-K30
20A Double Pole Switch with Neon

PACK: 80pcs 16



A66-C23-2
16A 2 Pin European Socket

PACK: 80pcs 33



A66-C17-2
15A 3 Round Pin Socket with Switch

PACK: 80pcs 34



A66-C38
15A 3 Round Pin Switched Socket with LED Indicator

PACK: 80pcs 35



A66-C06
2 Pin & 3 Pin Universal Socket

PACK: 80pcs 36



A66-K50-2
45A Double Pole Switch with LED Indicator

PACK: 80pcs 17



A66-C11
13A BS Socket

PACK: 80pcs 18



A66-C29
13A Single Switch Socket

PACK: 80pcs 19



A66-C12
13A BS Socket with Switch & Neon

PACK: 80pcs 20



A66-C36
16A 3 Pin Universal Socket with Switch

PACK: 80pcs 37



A66-C37
16A 3 Pin Universal Switched Socket with LED Indicator

PACK: 80pcs 38



A66-C45
16A 3 Pin Universal Socket with Night Light

PACK: 80pcs 39



A66-C06E29
2 Pin & 3 Pin Universal Socket with 2.1A Double USB Charger

PACK: 60pcs 40



A66-C06E24
16A 2 Pin & 3 Pin Universal Socket
with 3.4A Double USB Charger
PACK: 60pcs 41



A66-C06E32
2 Pin & 3 Pin Universal Socket
with Type A+C USB Charger
PACK: 60pcs 42



A66-E24-2
3.1A Double USB Charger
PACK: 60pcs 43



A66-E31
20W Type A+C USB Charger
PACK: 60pcs 44



A66-K22 A66-K24
Background/General Speaker
Voice Dimmer Switch
PACK: 60pcs 61



A66-K09
300W Light Dimmer Switch
PACK: 60pcs 62



A66-K10
630W Light Dimmer Switch
PACK: 60pcs 63



A66-K86
1000W Two Way Push Dimmer Switch
PACK: 60pcs 64



A66-E33
65W Type A+C USB Charger
PACK: 60pcs 45



A66-P37
45A Flex Outlet
PACK: 60pcs 46



A66-P38
25A Flex Outlet
PACK: 80pcs 47



A66-E01
Single Telephone Socket
PACK: 80pcs 48



A66-2K100
Twin 100W LED Dimmer Switch
PACK: 60pcs 65



A66-K11
300W Fan Dimmer Switch
PACK: 60pcs 66



A66-K88
300W Two Way Push Fan
Dimmer Switch
PACK: 60pcs 67



A66-K93
100W Step Fan Dimmer Switch
PACK: 40pcs 68



A66-E02
Computer Socket(CAT.6)
PACK: 80pcs 49



A66-E03
Single TV Socket
PACK: 80pcs 50



A66-2E01
Double Telephone Socket
PACK: 80pcs 51



A66-2E02
Double Computer Socket
(CAT.6)
PACK: 80pcs 52



A66-K12
Air Control Dimmer Switch
PACK: 60pcs 69



A66-K01BK09
300W Light Dimmer With
Two Way Rocker Switch
PACK: 60pcs 70



A66-K01BK11
300W Light Dimmer With
Two Way Rocker Switch
PACK: 60pcs 71



A66-K25
65-100W Voice Activated & Light
Sensor Switch with Time Delay
PACK: 80pcs 72



A66-E0102
Telephone & Computer Socket
(CAT.6)
PACK: 80pcs 53



A66-2E03
Double TV Socket
PACK: 80pcs 54



A66-E06
Single Satellite Socket
PACK: 80pcs 55



A66-E0608
TV & Satellite Socket
PACK: 80pcs 56



A66-K26
65-100W Touch Switch with
Time Delay
PACK: 80pcs 73



A66-K23
65-100W PIR Switch
PACK: 60pcs 74



A66-K85
PIR Floor Light
PACK: 80pcs 75



A66-K36
LED Foot Light
PACK: 60pcs 76



A66-E0103
Telephone & TV Socket
PACK: 80pcs 57



A66-E0203
Computer & TV Socket (CAT.6)
PACK: 80pcs 58



A66-E0206
Computer & Satellite Socket
Computer & Satellite Socket(CAT6)
PACK: 80pcs 59



A66-2E07
2 Gang Speaker Outlet
PACK: 80pcs 60



A66-K37
1W Buzzer
PACK: 80pcs 77



A66-K31
3A Alarm Switch
PACK: 80pcs 78



A66-K17
4A Bell Switch with "DO NOT
DISTURB" & "MAKE UP ROOM"
Indicator
PACK: 80pcs 79



A66-K18
4A Bell Switch with "DO NOT
DISTURB" & "MAKE UP ROOM"
Indicator
PACK: 80pcs 80



A66-K21
4A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Indicator
PACK: 80pcs 81



A66-K15
16A Key card Switch
PACK: 60pcs 82



A66-K43
16A Low Frequency Key Card Switch
PACK: 60pcs 83



A66-K44
16A High Frequency Key Card Switch
PACK: 60pcs 84



A66-C44
16A Twin Universal Switched Socket with Neon
PACK: 50pcs 101



A66-C44E24
16A Twin Universal Switched Socket with 2 Ports USB Charger & Neon
PACK: 40pcs 102



A66-C26
45A Cooker Unit
PACK: 50pcs 103



A66-K90
147 45A DP Switch
PACK: 50pcs 104



A66-K96
"DO NOT DISTURB" Switch
PACK: 80pcs 85



A66-K97
"DO NOT DISTURB" & "MAKE UP ROOM" Switch
PACK: 80pcs 86



A66-K98
"DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Switch
PACK: 80pcs 87



A66-C34
10VA 115V~ / 10A 230V~ Shaver Socket
PACK: 16 pcs 88



A66-P28
Double Blank Plate
PACK: 160pcs 105




A66-K74A A66-K74B
10AX 147 4 Gang Switch
PACK: 50pcs 106



A66-K75A A66-K75B
10AX 147 5 Gang Switch
PACK: 50pcs 107



A66-C08
Shaver Socket
PACK: 10pcs 89



A66-C13
13A Twin BS Socket
PACK: 50pcs 90



A66-C30-2
13A Twin BS Socket with Switch
PACK: 50pcs 91



A66-C14-2
13A Twin BS Socket with Switch & LED Indicator
PACK: 50pcs 92



A66-C39
13A Twin BS Socket with DP Switch
PACK: 50pcs 93



A66-C40
13A Twin BS Socket with DP Switch & LED Indicator
PACK: 50pcs 94



A66-C30E24
13A Twin Switched Socket with 2 Ports USB Charger
PACK: 40pcs 95



A66-C14E24
13A Twin Switched Socket with 2 Ports USB Charger & Neon
PACK: 40pcs 96



A66-C39E24
13A Twin DP Switched Socket with 2 Ports USB Charger
PACK: 40pcs 97



A66-C40E24
13A Twin DP Switched Socket with 2 Ports USB Charger & Neon
PACK: 40pcs 98



A66-C43
16A Twin Universal Switched Socket
PACK: 50pcs 99



A66-C43E24
16A Twin Universal Switched Socket with 2 Ports USB Charger
PACK: 40pcs 100

A68 SERIES

- Modern style design
- Purely flat switch with LED indicator
- Three color optional



A68-BK1A A68-BK1B
10AX 1 Gang Full-Flat Switch
with LED Indicator
PACK: 80pcs 1



A68-BK2A A68-BK2B
10AX 2 Gang Full-Flat Switch
with LED Indicator
PACK: 80pcs 2



A68-BK3A A68-BK3B
10AX 3 Gang Full-Flat Switch
with LED Indicator
PACK: 80pcs 3



A68-BK4A A68-BK4B
10AX 4 Gang Full-Flat Switch
with LED Indicator
PACK: 80pcs 4



A68-K77
10AX 1 Gang Intermediate Full-Flat
Switch with LED Indicator
PACK: 80pcs 5



A68-P01
Single Blank
PACK: 200pcs 6



A68-K45 A68-K46
5A/13A Switched Fused
Connection Unit with Neon
PACK: 80pcs 7



A68-K30
20A Double Pole Switch with
Neon
PACK: 80pcs 8



A68-K50-2
45A Double Pole Switch with
LED Indicator
PACK: 80pcs 9



A68-C11
13A BS Socket
PACK: 80pcs 10



A68-C29-3
13A Single Switch Socket
PACK: 80pcs 11



A68-C12-3
13A Single Switch Socket
with Neon
PACK: 80pcs 12



A68-C31
13A Single Socket with DP
Switch
PACK: 80pcs 13



A68-C32
13A Single Socket with DP
Switch & Neon
PACK: 80pcs 14



A68-C29E16
13A BS Switched Socket
with 2.1A USB Charger
PACK: 60pcs 15



A68-C31E16
13A Double Pole BS Switched
Socket with 2.1A USB Charger
PACK: 60pcs 16



A68-JAC28
16A 1 Gang Euro-American
Socket with Switch
PACK: 80pcs 17



A68-C28K
16A Switched Euro & American
Socket
PACK: 80pcs 18



A68-C28E24
16A Euro & American Socket
with 2 Ports USB Charge
PACK: 60pcs 19



A68-C28E32
16A Euro & American Socket
with Type A+C USB Charge
PACK: 60pcs 20



A68-C18-2
16A 2P + E German Socket

PACK: 80pcs 21



A68-C22-2
16A 2P+E French Socket

PACK: 80pcs 22



A68-C23-2
16A 2P European Socket

PACK: 80pcs 23



A68-C17-2
15A 3 Round Pin Socket
with Switch
PACK: 80pcs 24



A68-2E01
Double Telephone Socket
PACK: 80pcs 41



A68-2E02
Double Computer Socket
(CAT.6)
PACK: 80pcs 42



A68-E0102
Telephone & Computer Socket
(CAT.6)
PACK: 80pcs 43



A68-2E03
Double TV Socket
PACK: 80pcs 44



A68-C38
15A 3 Round Pin Switched
Socket with LED Indicator
PACK: 80pcs 25



A68-C06
16A 2 Pin & 3 Pin Universal
Socket
PACK: 80pcs 26



A68-C36
16A 3 Pin Universal Socket
with Switch
PACK: 80pcs 27



A68-C37
16A 3 Pin Universal Switched
Socket with LED Indicator
PACK: 80pcs 28



A68-E06
Single Satellite Socket
PACK: 80pcs 45



A68-E0608
TV & Satellite Socket
PACK: 80pcs 46



A68-E0103
Telephone & TV Socket
PACK: 80pcs 47



A68-E0203
Computer & TV Socket (CAT.6)
PACK: 80pcs 48



A68-C45
16A Switched Universal Socket
with Night Light
PACK: 80pcs 29



A68-C06E29
2 Pin & 3 Pin Universal Socket
with 2.1A Double USB Charger
PACK: 60pcs 30



A68-C06E24
2 Pin & 3 Pin Universal Socket
with 3.4A Double USB Charger
PACK: 60pcs 31



A68-C06E32
2 Pin & 3 Pin Universal Socket
with Type A+C USB Charger
PACK: 60pcs 32



A68-E0206
Computer & Satellite Socket (CAT6)
PACK: 80pcs 49



A68-2E07
2 Gang Speaker Outlet
PACK: 80pcs 50



A68-K22 **A68-K24**
Background/General Speaker
Voice Dimmer Switch
PACK: 60pcs 51



A68-K09
300W Light Dimmer Switch
PACK: 60pcs 52



A68-E24-2
3.1A Double USB Charger
PACK: 60pcs 33



A68-E31
20W Type A+C USB Charger
PACK: 60pcs 34



A68-E33
65W Type A+C USB Charger
PACK: 60pcs 35



A68-P37
45A Flex Outlet
PACK: 60pcs 36



A68-K10
630W Light Dimmer Switch
PACK: 60pcs 53



A68-K86
1000W Two Way Push Dimmer
Switch
PACK: 60pcs 54



A68-2K100
Twin 100W LED Dimmer Switch
PACK: 60pcs 55



A68-K11
300W Fan Dimmer Switch
PACK: 60pcs 56



A68-P38
25A Flex Outlet
PACK: 80pcs 37



A68-E01
Single Telephone Socket
PACK: 80pcs 38



A68-E02
Computer Socket (CAT.6)
PACK: 80pcs 39



A68-E03
Single TV Socket
PACK: 80pcs 40



A68-K88
300W Two Way Push Fan
Dimmer Switch
PACK: 60pcs 57



A68-K93
100W Step Fan Dimmer Switch
PACK: 40pcs 58



A68-K12
Air Control Dimmer Switch
PACK: 60pcs 59



A68-K01BK09
300W Light Dimmer With Two
Way Rocker Switch
PACK: 60pcs 60



A68-K01BK11
300W Fan Dimmer With Two
Way Rocker Switch
PACK: 60pcs 61



A68-K25
45-100W Voice Activated & Light
Sensor Switch with Time Delay
PACK: 80pcs 62



A68-K26
45-100W Touch Switch with
Time Delay
PACK: 80pcs 63



A68-K23
65-100W PIR Switch
PACK: 60pcs 64



A68-C30-2
13A Twin BS Socket with Switch
PACK: 50pcs 81



A68-C14-2
13A Twin BS Socket with Switch
& LED Indicator
PACK: 50pcs 82



A68-C39
13A Twin BS Socket with DP
Switch
PACK: 50pcs 83



A68-C40
13A Twin BS Socket with DP Switch
& LED Indicator
PACK: 50pcs 84



A68-K85
PIR Foot Light
PACK: 80pcs 65



A68-K36
15mA LED Foot Light
PACK: 60pcs 66



A68-K37
1W Buzzer
PACK: 80pcs 67



A68-K31
3A Alarm Switch
PACK: 80pcs 68



A68-C30E24
13A Twin Switched Socket with
2 Ports USB Charger
PACK: 40pcs 85



A68-C14E24
13A Twin Switched Socket with
2 Ports USB Charger & Neon
PACK: 40pcs 86



A68-C39E24
13A Twin DP Switched Socket
with 2 Ports USB Charger
PACK: 40pcs 87



A68-C40E24
13A Twin DP Switched Socket with
2 Ports USB Charger & Neon
PACK: 40pcs 88



A68-K17
4A Bell Swith with "DO NOT
DISTURB" Indicator
PACK: 80pcs 69



A68-K18
4A Bell Swith with "DO NOT DISTURB"
& "MAKE UP ROOM" Indicator
PACK: 80pcs 70



A68-K21
4A Bell Swith with "DO NOT DISTURB" &
"MAKE UP ROOM" & "PLEASE WAIT"
Indicator
PACK: 80pcs 71



A68-K15
16A Key card switch
PACK: 60pcs 72



A68-C43
16A Twin Universal Switched
Socket
PACK: 50pcs 89



A68-C43E24
16A Twin Universal Switched Socket
with 2 Ports USB Charger
PACK: 40pcs 90



A68-C44
16A Twin Universal Switched Socket
with Neon
PACK: 50pcs 91



A68-C44E24
16A Twin Universal Switched Socket
with 2 Ports USB Charger & Neon
PACK: 40pcs 92



A68-K43
Low Frequency Key Card Switch
PACK: 60pcs 73



A68-K44
High Frequency Key Card Switch
PACK: 60pcs 74



A68-K96
"DO NOT DISTURB" Switch
PACK: 80pcs 75



A68-K97
"DO NOT DISTURB" & "MAKE
UP ROOM" Switch
PACK: 80pcs 76



A68-C26
45A Cooker Unit
PACK: 50pcs 93



A68-K90
147 45A DP Switch
PACK: 50pcs 94



A68-P28
Double Blank Plate
PACK: 160pcs 95



A68-K74A A68-K74B
10AX 147 4 Gang Switch
PACK: 50pcs 96



A68-K98
"DO NOT DISTURB" & "MAKE UP
ROOM" & "PLEASE WAIT" Switch
PACK: 80pcs 77



A68-C34
10VA 115V~ / 10A 230V~
Shaver Socket
PACK:16 pcs 78



A68-C08
Shaver Socket
PACK: 10pcs 79



A68-C13
13A Twin BS Socket
PACK: 50pcs 80



A68-K75A A68-K75B
10AX 147 5 Gang Switch
PACK: 50pcs 97

A38 SERIES

- Mirror decorative strip LED light switch
- Reversing touch control technology, high power LED loading
- Large aperture connecting terminal



White



Golden



A38-K01A A38-K01B
10AX 1 Gang Switch Rocker

PACK: 80pcs 1



A38-K02A A38-K02B
10AX 2 Gang Switch Rocker

PACK: 80pcs 2



A38-K03A A38-K03B
10AX 3 Gang Switch Rocker

PACK: 80pcs 3



A38-K04A A38-K04B
10AX 4 Gang Switch Rocker

PACK: 80pcs 4



A38-K16
10A Doorbell Switch

PACK: 80pcs 5



A38-K19
10AX 1 Gang Intermediate Switch

PACK: 80pcs 6



A38-K20
10AX 2 Gang Intermediate Switch

PACK: 80pcs 7



A38-P01
Single Blank

PACK: 200pcs 8



A38-K45 A38-K46
5A / 13A Switched Fused
Connection Unit with Neon

PACK: 80pcs 9



A38-K30
20A Double Pole Switch
with Neon

PACK: 80pcs 10



A38-K50-2
45A Double Pole Switch with
LED Indicator

PACK: 80pcs 11



A38-C11-2
13A BS Socket

PACK: 80pcs 12



A38-C29-3
13A Single Switch Socket

PACK: 80pcs 13



A38-C12-3
13A Single Switch Socket
with Neon

PACK: 80pcs 14



A38-C31-2
13A BS Socket with DP Switch

PACK: 80pcs 15



A38-C32-2
13A BS Socket with DP Switch
& LED Indicator

PACK: 80pcs 16



A38-C29E16
13A BS Switched Socket with
2.1A USB Charger

PACK: 60pcs 17




A38-C31E16
13A Double Pole BS Switched
Socket with 2.1A USB Charger

PACK: 60pcs 18



A38-JAC28
16A 1 Gang Euro-American
Socket with Switch

PACK: 80pcs 19



A38-C28K
16A Switched Euro & American
Socket


PACK: 80pcs 20



A38-C28E24
16A Euro & American Socket
with 2 Ports USB Charge
PACK: 60pcs 21



A38-C28E32
16A Euro & American Socket
with Type A+C USB Charge
PACK: 60pcs 22



A38-C42
16A Twin Euro & American Socket
PACK: 80pcs 23



A38-C18-2
16A 2P + E German Socket
PACK: 80pcs 24



A38-E01
Single Telephone Socket
PACK: 80pcs 41



A38-E02
Single Computer Socket
PACK: 80pcs 42



A38-E03
Single TV Socket
PACK: 80pcs 43



A38-2E01
Double Telephone Socket
PACK: 80pcs 44



A38-C22-2
16A 2P+E French Socket
PACK: 80pcs 25



A38-C23-2
16A 2P European Socket
PACK: 80pcs 26



A38-C17-2
15A 3 Round Pin Socket
with Switch
PACK: 80pcs 27



A38-C38
15A 3 Round Pin Switched
Socket with LED Indicator
PACK: 80pcs 28



A38-2E02
Double Computer Socket
(CAT.6)
PACK: 80pcs 45



A38-E0102
Telephone & Computer Socket
(CAT.6)
PACK: 80pcs 46



A38-2E03
Double TV Socket
PACK: 80pcs 47



A38-E06
Single Satellite Socket
PACK: 80pcs 48




A38-C06
16A 2 Pin & 3 Pin Universal
Socket
PACK: 80pcs 29



A38-C36
16A 3 Pin Universal Socket
with Switch
PACK: 80pcs 30



A38-C37
16A 3 Pin Universal Switched
Socket with LED Indicator Module
PACK: 80pcs 31



A38-C45
16A Switched Universal Socket
with Night Light
PACK: 80pcs 32



A38-E0608
TV & Satellite Socket
PACK: 80pcs 49



A38-E0103
Telephone & TV Socket
PACK: 80pcs 50



A38-E0203
Computer & TV Socket
(CAT.6)
PACK: 80pcs 51



A38-E0206
Computer & Satellite Socket
(CAT.6)
PACK: 80pcs 52



A38-C06E29
2 Pin & 3 Pin Universal Socket
with 2.1A Double USB Charger
PACK: 60pcs 33



A38-C06E24
16A 2 Pin & 3 Pin Universal Socket
with 3.4A Double USB Charger
PACK: 60pcs 34



A38-C06E32
2 Pin & 3 Pin Universal Socket
with Type A+C USB Charger
PACK: 60pcs 35



A38-E24-2
3.1A Double USB Charger
PACK: 60pcs 36



A38-2E07
2 Gang Speaker Outlet
PACK: 80pcs 53



A38-K09
300W Light Dimmer Switch
PACK: 60pcs 54



A38-K86
1000W Two Way Push Dimmer
Switch
PACK: 60pcs 55



A38-2K100
Twin 100W LED Dimmer Switch
PACK: 60pcs 56



A38-E31
20W Type A+C USB Charger
PACK: 60pcs 37



A38-E33
65W Type A+C USB Charger
PACK: 60pcs 38



A38-P37
45A Flex Outlet
PACK: 60pcs 39



A38-P38
25A Flex Outlet
PACK: 80pcs 40



A38-K11
300W Fan Dimmer Switch
PACK: 60pcs 57



A38-K88
300W Two Way Push Fan
Dimmer Switch
PACK: 60pcs 58



A38-K93
100W Step Fan Dimmer Switch
PACK: 40pcs 59



A38-K12
Air Control Dimmer Switch
PACK: 60pcs 60



A38-K01BK09
300W Light Dimmer With
Two Way Rocker Switch
PACK: 60pcs 61




A38-K01BK11
300W Fan Dimmer With Two
Way Rocker Switch
PACK: 60pcs 62




A38-K25
65-100W Voice Activated & Light
Sensor Switch with Time Delay
PACK: 80pcs 63



A38-K26
65-100W Touch Switch with
Time Delay
PACK: 80pcs 64




A38-C13
13A Twin BS Socket
PACK: 50pcs 81



A38-C30
13A Twin Switched Socket
PACK: 50pcs 82



A38-C14
13A Twin Socket with switch
& LED Indicator
PACK: 50pcs 83



A38-C39
13A DP Twin Switched Socket
PACK: 50pcs 84



A38-K23
65-100W PIR Switch
PACK: 60pcs 65



A38-K85
PIR Foot Light
PACK: 80pcs 66



A38-K36
LED Foot Light
PACK: 80pcs 67



A38-K37
1W Buzzer
PACK: 80pcs 68



A38-C40
13A DP Twin Socket with switch
& LED Indicator
PACK: 50pcs 85



A38-C30E24
13A Twin Switched Socket with
2 Ports USB Charger
PACK: 40pcs 86



A38-C14E24
13A Twin Switched Socket with
2 Ports USB Charger & Neon
PACK: 40pcs 87



A38-C39E24
13A Twin DP Switched Socket
with 2 Ports USB Charger
PACK: 40pcs 88



A38-K31
3A Alarm Switch
PACK: 80pcs 69



A38-K17
2A Bell Switch with
"DO NOT DISTURB" Indicator
PACK: 80pcs 70



A38-K18
2A Bell Switch with "DO NOT DISTURB"
& "MAKE UP ROOM" Indicator
PACK: 80pcs 71



A38-K21
2A Bell Switch with "DO NOT DISTURB"&
"MAKE UP ROOM" & "PLEASE WAIT"
Indicator
PACK: 80pcs 72




A38-C40E24
13A Twin DP Switched Socket
with 2 Ports USB Charger & Neon
PACK: 40pcs 89



A38-C43
16A Twin Universal Switched
Socket
PACK: 50pcs 90



A38-C43E24
16A Twin Universal Switched Socket
with 2 Ports USB Charger
PACK: 40pcs 91



A38-C44
16A Twin Universal Switched Socket
with Neon
PACK: 50pcs 92



A38-K15
16A KeyCard Switch
PACK: 60pcs 73



A38-K43
16A Low Frequency
KeyCard Switch
PACK: 60pcs 74



A38-K44
16A High Frequency
KeyCard Switch
PACK: 60pcs 75



A38-K96
"DO NOT DISTURB" Switch
PACK: 80pcs 76



A38-C44E24
16A Twin Universal Switched Socket
with 2 Ports USB Charger & Neon
PACK: 40pcs 93



A38-C26
45A Cooker Unit
PACK: 50pcs 94



A38-K90
147 45A DP Switch
PACK: 50pcs 95



A38-P28
Double Blank
PACK: 160pcs 96



A38-K97
"DO NOT DISTURB" & "MAKE
UP ROOM" Switch
PACK: 80pcs 77



A38-K98
"DO NOT DISTURB" & "MAKE UP
ROOM" & "PLEASE WAIT" Switch
PACK: 80pcs 78



A38-C34
3X3 Shaver Socket
PACK: 16pcs 79



A38-C08
Shaver Socket
PACK: 10pcs 80

D3 SERIES

- Simple Large Panel Design
- High Current Load Design For Larger LED Loading
- Large Size Sliding Terminal For Easier Wiring



D3-K01A D3-K01B
10AX 1 Gang Switch

PACK: 100pcs 1



D3-K02A D3-K02B
10AX 2 Gang Switch

PACK: 100pcs 2



D3-K03A D3-K03B
10AX 3 Gang Switch

PACK: 100pcs 3



D3-K04A D3-K04B
10AX 4 Gang Switch

PACK: 100pcs 4



V8-K16
10A Doorbell Switch

PACK: 100pcs 5



V8-K16
10A 1 Gang Retractive Switch

PACK: 100pcs 6



D3-K19
10AX 1 Gang Intermediate Switch

PACK: 100pcs 7



D3-K20
10AX 2 Gang Intermediate Switch

PACK: 100pcs 8



D3-P01
Single Blank Plate

PACK: 200pcs 9



D3-K45 D3-K46
5A/13A Switched Fused Connection Unit with Neon

PACK: 100pcs 10



D3-K30
20A Double Pole Switch with Neon

PACK: 100pcs 11



D3-K50
45A Double Pole Switch with LED Indicator

PACK: 100pcs 12



D3-C11
13A BS Socket

PACK: 100pcs 13



D3-C29
13A BS Socket with Switch

PACK: 100pcs 14



D3-C12
13A Single Switched Socket with Neon

PACK: 100pcs 15



D3-C31
13A BS Socket with DP Switch

PACK: 100pcs 16



D3-C32
13A Single Socket with DP Switch & Neon

PACK: 100pcs 17



D3-C29E16
13A BS Switched Socket with 2.1A USB Charger

PACK: 80pcs 18




D3-C31E16
13A Double Pole BS Switched Socket with 2.1A USB Charger

PACK: 80pcs 19



D3-JAC28
16A 1 Gang Euro-American Socket with Switch

PACK: 100pcs 20

							
D3-C28K 16A Switched Euro & American Socket PACK: 100pcs 21	D3-C28E24 16A Euro & American Socket with 2 Ports USB Charge PACK: 80pcs 22	D3-C28E32 16A Euro & American Socket with Type A+C USB Charge PACK: 80pcs 23	D3-C42 16A Twin Euro & American Socket PACK: 100pcs 24	D3-P38 25A Flex Outlet PACK: 100pcs 41	D3-E01 Single Telephone Socket PACK: 100pcs 42	D3-E02 Single Computer Socket PACK: 100pcs 43	D3-E03 Single TV Socket PACK: 100pcs 44
							
D3-C18 16A 2P + E German Socket PACK: 100pcs 25	D3-C22 16A 2P+E French Socket PACK: 100pcs 26	D3-C23 16A 2P European Socket PACK: 100pcs 27	D3-C17 15A 3 Round Pin Socket with Switch PACK: 100pcs 28	D3-2E01 Double Telephone Socket PACK: 100pcs 45	D3-2E02 Double Computer Socket (CAT.6) PACK: 100pcs 46	D3-E0102 Telephone & Computer Socket (CAT.6) PACK: 100pcs 47	D3-2E03 Double TV Socket PACK: 100pcs 48
							
D3-C38 15A 3 Round Pin Switched Socket with LED Indicator PACK: 100pcs 29	D3-C06 16A 2 Pin & 3 Pin Universal Socket PACK: 100pcs 30	D3-C36 16A 3 Pin Universal Socket with Switch PACK: 100pcs 31	D3-C37 16A 3 Pin Universal Switched Socket with LED Indicator PACK: 100pcs 32	D3-E06 Single Satellite Socket PACK: 100pcs 49	D3-E0608 TV & Satellite Socket PACK: 100pcs 50	D3-E0103 Telephone & TV Socket PACK: 100pcs 51	D3-E0203 Computer & TV Socket (CAT.6) PACK: 100pcs 52
							
D3-C45 16A Switched Universal Socket with Night Light PACK: 80pcs 33	D3-C06E29 2 Pin & 3 Pin Universal Socket with 2.1A Double USB Charger PACK: 80pcs 34	D3-C06E24 16A 2 Pin & 3 Pin Universal Socket with 3.4A Double USB Charger PACK: 80pcs 35	D3-C06E32 2 Pin & 3 Pin Universal Socket with Type A+C USB Charger PACK: 80pcs 36	D3-E0206 Computer & Satellite Socket (CAT6) PACK: 100pcs 53	D3-2E07 2 Gang Speaker Outlet PACK: 100pcs 54	D3-K22 D3-K24 Background/General Speaker Voice Dimmer Switch PACK: 80pcs 55	D3-K09 300W Light Dimmer Switch PACK: 80pcs 56
							
D3-E24-2 3.1A Double USB Charger PACK: 80pcs 37	D3-E31 20W Type A+C USB Charger PACK: 80pcs 38	D3-E33 65W Type A+C USB Charger PACK: 80pcs 39	D3-P37 45A Flex Outlet PACK: 80pcs 40	D3-K10 630W Light Dimmer Switch PACK: 80pcs 57	D3-K86 1000W Two Way Push Dimmer Switch PACK: 60pcs 58	D3-2K100 Twin 100W LED Dimmer Switch PACK: 80pcs 59	D3-K11 300W Fan Dimmer Switch PACK: 80pcs 60



D3-K88
300W Two Way Push Fan
Dimmer Switch
PACK: 60pcs

61



D3-K93
100W Step Fan Dimmer Switch
PACK: 60pcs

62



D3-K12
Air Control Dimmer Switch
PACK: 80pcs

63



D3-K01BK09
300W Light Dimmer With
Two Way Rocker Switch
PACK: 80pcs

64



D3-K98
"DO NOT DISTURB" & "MAKE UP
ROOM" & "PLEASE WAIT" Switch
PACK: 100pcs

81




D3-C34
10VA 115V~ / 10A 230V~
Shaver Socket
PACK: 16pcs

82



D3-C08
3X6 Shaver Socket
PACK: 10pcs

83



D3-C13
13A Twin BS Socket
PACK: 70pcs

84



D3-K01BK11
300W Fan Dimmer With Two
Way Rocker Switch
PACK: 80pcs

65



D3-K25
Acoustooptic Controlled Switch
with Time Delay
PACK: 100pcs

66



D3-K26
Touch Switch with Time Delay
PACK: 100pcs

67



D3-K23
PIR Switch
PACK: 80pcs

68



D3-C30
13A Twin BS Socket with
Switch
PACK: 70pcs

85



D3-C14
13A Twin BS Socket with
Switch & LED Indicator
PACK: 70pcs

86



D3-C39
13A Twin BS Socket with DP Switch
PACK: 70pcs

87



D3-C40
13A Twin BS Socket with DP
Switch & LED Indicator
PACK: 70pcs

88



D3-K85
PIR Foot Light
PACK: 100pcs

69



D3-K36
15mA LED Foot Light
PACK: 100pcs

70



D3-K37
1W Buzzer
PACK: 100pcs

71



D3-K31
3A Alarm Switch
PACK: 100pcs

72



D3-C30E24
13A Twin Switched Socket with
2 Ports USB Charger
PACK: 40pcs

89



D3-C14E24
13A Twin Switched Socket with
2 Ports USB Charger & Neon
PACK: 40pcs

90



D3-C39E24
13A Twin DP Switched Socket with
2 Ports USB Charger
PACK: 40pcs

91



D3-C40E24
13A Twin DP Switched Socket with
2 Ports USB Charger & Neon
PACK: 40pcs

92



D3-K17
4A Bell Switch with "DO NOT DISTURB"
Indicator
PACK: 100pcs

73



D3-K18
4A Bell Switch with "DO NOT DISTURB"
& "MAKE UP ROOM" Indicator
PACK: 100pcs

74



D3-K21
4A Bell Switch with "DO NOT DISTURB"&
"MAKE UP ROOM" & "PLEASE WAIT"
Indicator
PACK: 100pcs

75



D3-K15
16A KeyCard Switch
PACK: 80pcs

76



D3-C43
16A Twin Universal Switched Socket
PACK: 60pcs

93



D3-C43E24
16A Twin Universal Switched Socket
with 2 Ports USB Charger
PACK: 40pcs

94



D3-C44
16A Twin Universal Switched Socket
with Neon
PACK: 60pcs

95



D3-C44E24
16A Twin Universal Switched Socket
with 2 Ports USB Charger & Neon
PACK: 40pcs

96



D3-K43
16A Low Frequency
KeyCard Switch
PACK: 80pcs

77



D3-K44
16A High Frequency
KeyCard Switch
PACK: 80pcs

78



D3-K96
"DO NOT DISTURB" Switch
PACK: 100pcs

79



D3-K97
"DO NOT DISTURB" &
"MAKE UP ROOM" Switch
PACK: 100pcs

80



D3-C26
45A Cooker Unit
PACK: 50pcs

97



D3-K90
147 45A DP Switch
PACK: 60pcs

98



D3-P28
Double Blank Plate
PACK: 140pcs

99

A63 SERIES

- Frameless design with big cambered surface
- Golden White optional
- Reversing touch control technology, high power LED loading.
- Large aperture connecting terminal



A63-K01A A63-K01B
10AX 1 Gang Switch Rocker
PACK: 100pcs 1



A63-K02A A63-K02B
10AX 2 Gang Switch Rocker
PACK: 100pcs 2



A63-K03A A63-K03B
10AX 3 Gang Switch Rocker
PACK: 100pcs 3



A63-K04A A63-K04B
10AX 4 Gang Switch Rocker
PACK: 100pcs 24



A63-K16
10A Doorbell Switch
PACK: 100pcs 5



A63-K16
10A 1 Gang Retractive Switch
PACK: 100pcs 6



A63-K19
10AX 1 Gang Intermediate Switch
PACK: 100pcs 7



A63-K20
10AX 2 Gang Intermediate Switch
PACK: 100pcs 8



A63-K45
5A Switched Fused Connection Unit with Neon
PACK: 100pcs 9



A63-K30
20A Double Pole Switch with Neon
PACK: 100pcs 10



A63-K50-2
45A Double Pole Switch with LED Indicator
PACK: 100pcs 11



A63-C11-2
13A BS Socket
PACK: 100pcs 12



A63-C29-3
13A Single Switch Socket
PACK: 100pcs 13



A63-C12-3
13A Single Switch Socket with Neon
PACK: 100pcs 14



A63-C31-2
13A BS Socket with DP Switch
PACK: 100pcs 15



A63-C32-2
13A BS Socket with DP Switch & LED Indicator
PACK: 100pcs 16



A63-C29E16
13A BS Switched Socket with 2.1A USB Charger
PACK: 80pcs 17



A63-C31E16
13A Double Pole BS Switched Socket with 2.1A USB Charger
PACK: 80pcs 18



A63-JAC28
16A 1 Gang Euro-American Socket with Switch
PACK: 100pcs 19



A63-C28K
16A Switched Euro & American Socket
PACK: 100pcs 20

							
A63-C28E24 16A Euro & American Socket with 2 Ports USB Charge PACK: 80pcs 21	A63-C28E32 16A Euro & American Socket with Type A+C USB Charge PACK: 80pcs 22	A63-C42 16A Twin Euro & American Socket PACK: 100pcs 23	A63-C18 16A 2P + E German Socket PACK: 100pcs 24	A63-E01 Single Telephone Socket PACK: 100pcs 41	A63-E02 Single Computer Socket PACK: 100pcs 42	A63-E03 Single TV Socket PACK: 100pcs 43	A63-2E01 Double Telephone Socket PACK: 100pcs 44
							
A63-C22 16A 2P+E French Socket PACK: 100pcs 25	A63-C23 16A 2P European Socket PACK: 100pcs 26	A63-C17-2 15A 3 Round Pin Socekt with Switch PACK: 100pcs 27	A63-C38 15A 3 Round Pin Switched Socket with LED Indicator PACK: 100pcs 28	A63-2E02 Double Computer Socket (CAT.6) PACK: 100pcs 45	A63-E0102 Telephone &Computer Socket(CAT.6) PACK: 100pcs 46	A63-2E03 Double TV Socket PACK: 100pcs 47	A63-E06 Single Satellite Socket PACK: 100pcs 48
							
A63-C06 16A 2 Pin & 3 Pin Universal Socket PACK: 100pcs 29	A63-C36 16A 3 Pin Universal Socket with Switch PACK: 100pcs 30	A63-C37 16A 3 Pin Universal Switched Socket with LED Indicator Module PACK: 100pcs 31	A63-C45 16A Switched Universal Socket with Night Light PACK: 100pcs 32	A63-E0608 TV & Satellite Socket PACK: 100pcs 49	A63-E0103 Telephone &TV Socket PACK: 100pcs 50	A63-E0203 Computer & TV Socket PACK: 100pcs 51	A63-E0206 Computer & Satellite Socket (CAT6) PACK: 100pcs 52
							
A63-JAC06-L 16A 2 Pin & 3 Pin Universal Switched Socket with Neon PACK: 100pcs 33	A63-C06E24 16A 2 Pin & 3 Pin Universal Socket with 3.4A Double USB Charger PACK: 80pcs 34	A63-C06E32 2 Pin & 3 Pin Universal Socket with Type A+C USB Charger PACK: 80pcs 35	A63-E24-2 3.1A Double USB Charger PACK: 80pcs 36	A63-2E07 2 Gang Speaker Outlet PACK: 100pcs 53	A63-K22 A63-K24 Background/General Speaker Voice Dimmer Switch PACK: 80pcs 54	A63-K09 300W Light Dimmer Switch PACK: 80pcs 55	A63-K10 630W Light Dimmer Switch PACK: 80pcs 56
							
A63-E31 20W Type A+C USB Charger PACK: 80pcs 37	A63-E33 65W Type A+C USB Charger PACK: 80pcs 38	A63-P37 45A Flex Outlet PACK: 80pcs 39	A63-P38 25A Flex Outlet PACK: 100pcs 40	A63-K86 1000W Two Way Push Dimmer Switch PACK: 60pcs 57	A63-2K100 Twin 100W LED Dimmer Switch PACK: 80pcs 58	A63-K11 300W Fan Dimmer Switch PACK: 80pcs 59	A63-K88 300W Two Way Push Fan Dimmer Switch PACK: 60pcs 60

							
A63-K93 100W Step Fan Dimmer Switch PACK: 60pcs 61	A63-K12 Air Control Dimmer Switch PACK: 80pcs 62	A63-K01BK09 300W Light Dimmer With Two Way Rocker Switch PACK: 80pcs 63	A63-K01BK11 300W Fan Dimmer With Two Way Rocker Switch PACK: 80pcs 64	A63-C34 10VA 115V~ / 10A 230V~ Shaver Socket PACK: 16pcs 81	A63-C08 Shaver Socket PACK: 10pcs 82	A63-C13 13A Twin BS Socket PACK: 70pcs 83	A63-C30-2 13A Twin BS Socket with Switch PACK: 70pcs 84
							
A63-K25 45-100W Voice Activated & Light Sensor Switch with Time Delay PACK: 100pcs 65	A63-K26 45-100W Touch Switch with Time Delay PACK: 100pcs 66	A63-K23 65-100W PIR Switch PACK: 80pcs 67	A63-K85 PIR Foot Light PACK: 80pcs 68	A63-C14-2 13A Twin BS Socket with Switch & LED Indicator PACK: 70pcs 85	A63-C39 13A Twin BS Socket with DP Switch PACK: 70pcs 86	A63-C40 13A Twin BS Socket with DP Switch & LED Indicator PACK: 70pcs 87	A63-C30E24 13A Twin Switched Socket with 2 Ports USB Charger PACK: 40pcs 88
							
A63-K36 15mA LED Foot Light PACK: 100pcs 69	A63-K37 1W Buzzer PACK: 100pcs 70	A63-K31 3A Alarm Switch PACK: 100pcs 71	A63-K17 4A Bell Switch with "DO NOT DISTURB" Indicator PACK: 100pcs 72	A63-C14E24 13A Twin Switched Socket with 2 Ports USB Charger & Neon PACK: 40pcs 89	A63-C39E24 13A Twin DP Switched Socket with 2 Ports USB Charger & Neon PACK: 40pcs 90	A63-C40E24 13A Twin DP Switched Socket with 2 Ports USB Charger & Neon PACK: 40pcs 91	A63-C43 16A Twin Universal Switched Socket PACK: 60pcs 92
							
A63-K18 4A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" Indicator PACK: 100pcs 73	A63-K21 4A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Indicator PACK: 100pcs 74	A63-K15 16A KeyCard Switch PACK: 80pcs 75	A63-K43 16A Low Frequency KeyCard Switch PACK: 80pcs 76	A63-C43E24 16A Twin Universal Switched Socket with 2 Ports USB Charger PACK: 40pcs 93	A63-C44 16A Twin Universal Switched Socket with Neon PACK: 60pcs 94	A63-C44E24 16A Twin Universal Switched Socket with 2 Ports USB Charger & Neon PACK: 40pcs 95	A63-C26 45A Cooker Unit PACK: 60pcs 96
							
A63-K44 16A High Frequency KeyCard Switch PACK: 80pcs 77	A63-K96 "DO NOT DISTURB" Switch PACK: 100pcs 78	A63-K97 "DO NOT DISTURB" & "MAKE UP ROOM" Switch PACK: 100pcs 79	A63-K98 "DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Switch PACK: 100pcs 80	A63-K90 147 45A DP Switch PACK: 60pcs 97	A63-P28 Double Blank Plate PACK: 140pcs 98		

E3 SERIES

- Modern minimalist design
- 16AX High-current rocker switch
- Purely flat switch with LED indicator



E-K01A E-K01B
16AX 1 Gang Switch Rocker
PACK: 80pcs 1



E-K02A E-K02B
16AX 2 Gang Switch Rocker
PACK: 80pcs 2



E-K03A E-K03B
16AX 3 Gang Switch Rocker
PACK: 80pcs 3



E-K04A E-K04B
10AX 4 Gang Switch Rocker
PACK: 80pcs 4




E9-K16
16A Doorbell Switch
PACK: 80pcs 5




E9-K16
16A 1 Gang Retractive Switch
PACK: 80pcs 6




E-K19
10AX 1 Gang Intermediate Switch
PACK: 80pcs 7



E-K20
10AX 2 Gang Intermediate Switch
PACK: 80pcs 8



E3-BK1A E3-BK1B
10AX 1 Gang Full-Flat Switch with LED Indicator
PACK: 80pcs 9




E3-BK12A E3-BK2B
10AX 2 Gang Full-Flat Switch with LED Indicator
PACK: 80pcs 10



E3-BK3A E3-BK3B
10AX 3 Gang Full-Flat Switch with LED Indicator
PACK: 80pcs 11



E3-BK4A E3-BK4B
10AX 4 Gang Full-Flat Switch with LED Indicator
PACK: 80pcs 12



E-P01
Single Blank Plate
PACK: 200pcs 13



E-K45 E-K46
5A / 13A Fuse Switch
PACK: 80pcs 14



E-K30
20A Double Pole Switch with Neon
PACK: 80pcs 15



E-K50-2
45A Double Pole Switch with LED Indicator
PACK: 80pcs 16



E-C11
13A BS Socket
PACK: 80pcs 17



E-C29-3
13A BS Socket with Switch
PACK: 80pcs 18



E-C12-3
13A BS Socket with Switch & LED Indicator
PACK: 80pcs 19



E-C31-2
13A BS Socket with DP Switch
PACK: 80pcs 20



E-C32-2
13A BS Socket with DP Switch
& LED Indicator
PACK: 80pcs 21



E3-C29E16
13A BS Switched Socket with
2.1A USB Charger
PACK: 60pcs 22



E3-C31E16
13A Double Pole BS Switched
Socket with 2.1A USB Charger
PACK: 60pcs 23



E-JAC28
16A 1 Gang Euro-American
Socket with Switch
PACK: 80pcs 24



E3-E31
20W Type A+C USB Charger
PACK: 60pcs 41




E3-E33
65W Type A+C USB Charger
PACK: 60pcs 42




E3-P37
45A Flex Outlet
PACK: 60pcs 43



E3-P38
25A Flex Outlet
PACK: 80pcs 44



E3-C28K
16A Switched Euro & American
Socket
PACK: 80pcs 25



E3-C28E24
16A Euro & American Socket
with 2 Ports USB Charge
PACK: 60pcs 26



E3-C28E32
16A Euro & American Socket
with Type A+C USB Charge
PACK: 60pcs 27



E-C18-2
16A 2P + E German Socket
PACK: 80pcs 28



E-E01
Single Telephone Socket
PACK: 80pcs 45



E-E02
Single Computer Socket
PACK: 80pcs 46



E-E03
Single TV Socket
PACK: 80pcs 47



E-2E01
Double Telephone Socket
PACK: 80pcs 48



E-C22-2
16A 2P+E French Socket
PACK: 80pcs 29



E-C23-2
16A 2P European Socket
PACK: 80pcs 30



E-C17-2
15A 3 Round Pin Socket
with Switch
PACK: 80pcs 31



E-C38
15A 3 Round Pin Switched
Socket with LED Indicator
PACK: 80pcs 32



E-2E02
Double Computer Socket
(CAT.6)
PACK: 80pcs 49



E-E0102
Telephone & Computer Socket
(CAT.6)
PACK: 80pcs 50



E-2E03
Double TV Socket
PACK: 80pcs 51



E-E06
Single Satellite Socket
PACK: 80pcs 52



E-C06
16A 2 Pin & 3 Pin Universal
Socket
PACK: 80pcs 33



E-C36
16A 3 Pin Universal Socket
with Switch
PACK: 80pcs 34



E-C37
16A 3 Pin Universal Switched
Socket with LED Indicator
PACK: 80pcs 35



E3-C45
16A Switched Universal Socket
with Night Light
PACK: 80pcs 36



E-E0608
TV & Satellite Socket
PACK: 80pcs 53



E-E0103
Telephone & TV Socket
PACK: 80pcs 54



E-E0203
Computer & TV Socket
PACK: 80pcs 55



E-E0206
Computer & Satellite Socket
(CAT6)
PACK: 80pcs 56



E3-C06E29
16A 2 Pin & 3 Pin Universal Socket
with 3.4A Double USB Charger
PACK: 60pcs 37



E3-C06E24
16A 2 Pin & 3 Pin Universal Socket
with 3.4A Double USB Charger
PACK: 60pcs 38



E3-C06E32
2 Pin & 3 Pin Universal Socket
with Type A+C USB Charger
PACK: 60pcs 39



E3-E24-2
3.1A Double USB Charger
PACK: 60pcs 40



E-2E07
2 Gang Speaker Outlet
PACK: 80pcs 57





E-K22 E-K24
Background/General Speaker
Voice Dimmer Switch
PACK: 60pcs 58



E-K09
300W Light Dimmer Switch
PACK: 60pcs 59




E-K10
630W Light Dimmer Switch
PACK: 60pcs 60

							
E-K86 1000W Two Way Push Dimmer Switch PACK: 60pcs 71	E3-2K100 Twin 100W LED Dimmer Switch PACK: 60pcs 72	E-K11 300W Fan Dimmer Switch PACK: 60pcs 73	E3-K88 300W Two Way Push Fan Dimmer Switch PACK: 60pcs 74	E-K44 16A High Frequency KeyCard Switch PACK: 60pcs 91	E3-K96 "DO NOT DISTURB" Switch PACK: 80pcs 92	E3-K97 "DO NOT DISTURB" & "MAKE UP ROOM" Switch PACK: 80pcs 93	E3-K98 "DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Switch PACK: 80pcs 94
							
E3-K93 100W Step Fan Dimmer Switch PACK: 40pcs 75	E-K12 Air Control Dimmer Switch PACK: 60pcs 76	E3-K01BK09 300W Light Dimmer With Two Way Rocker Switch PACK: 60pcs 77	E3-K01BK11 300W Fan Dimmer With Two Way Rocker Switch PACK: 60pcs 78	E-C34 3X3 Shaver Socket PACK: 16pcs 95	E-C08 3X6 Shaver Socket PACK: 10pcs 96	E-C13 13A Twin BS Socket PACK: 50pcs 97	E-C30-2 13A Twin BS Socket with Switch PACK: 50pcs 98
							
E-K25 65-100W Voice Activated & Light Sensor Switch with Time Delay PACK: 80pcs 79	E-K26 65-100W Touch Switch with Time Delay PACK: 80pcs 80	E-K23 65-100W PIR Switch PACK: 60pcs 81	E-K85 PIR Foot Light PACK: 80pcs 82	E-C14-2 13A Twin BS Socket with Switch & LED Indicator PACK: 50pcs 99	E-C39 13A Twin BS Socket with DP Switch PACK: 50pcs 100	E-C40 13A Twin BS Socket with DP Switch & LED Indicator PACK: 50pcs 101	E3-C30E24 13A Twin Switched Socket with 2 Ports USB Charger PACK: 40pcs 102
							
E-K36 LED Foot Light PACK: 60pcs 83	E-K37 1W Buzzer PACK: 80pcs 84	E-K31 3A Alarm Switch PACK: 80pcs 85	E-K17 4A Bell Switch with "DO NOT DISTURB" Indicator PACK: 80pcs 86	E3-C14E24 13A Twin Switched Socket with 2 Ports USB Charger & Neon PACK: 40pcs 103	E3-C39E24 13A Twin DP Switched Socket with 2 Ports USB Charger PACK: 40pcs 104	E3-C40E24 13A Twin DP Switched Socket with 2 Ports USB Charger & Neon PACK: 40pcs 105	E3-C43 16A Twin Universal Switched Socket PACK: 50pcs 106
							
E-K18 4A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" Indicator PACK: 80pcs 87	E-K21 4A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Indicator PACK: 80pcs 88	E-K15 16A KeyCard Switch PACK: 60pcs 89	E-K43 16A Low Frequency KeyCard Switch PACK: 60pcs 90	E3-C43E24 16A Twin Universal Switched Socket with 2 Ports USB Charger PACK: 40pcs 107	E3-C44 16A Twin Universal Switched Socket with Neon PACK: 50pcs 108	E3-C44E24 16A Twin Universal Switched Socket with 2 Ports USB Charger & Neon PACK: 40pcs 109	E-C26 45A Cooker Unit PACK: 50pcs 110



E3-K90
147 45A DP Switch

PACK: 50pcs 111




E-P28
Double Blank Plate

PACK: 160pcs 112



E-K74A E-K74B
10AX 147 4 Gang Switch

PACK: 50pcs 113

















E-K75A E-K75B
10AX 147 5 Gang Switch

PACK: 50pcs 114

B3 SERIES

- Classic exterior design
- Complete functional series
- Cost-effective series




							
A30-BK01A A30-BK01B 16AX 1 Gang Switch Rocker PACK: 100pcs 1	A30-BK02A A30-BK02B 16AX 2 Gang Switch Rocker PACK: 100pcs 2	A30-BK03A A30-BK03B 16AX 3 Gang Switch Rocker PACK: 100pcs 3	A30-K04A A30-K04B 10AX 4 Gang Switch Rocker PACK: 100pcs 4	A30-C28K 16A Switched Euro & American Socket PACK: 100pcs 21	A30-C28E24 16A Euro & American Socket with 2 Ports USB Charge PACK: 80pcs 22	A30-C28E32 16A Euro & American Socket with Type A+C USB Charge PACK: 80pcs 23	A30-C18-2 16A 2P + E German Socket PACK: 100pcs 24
							
A-K16 16A Doorbell Switch PACK: 100pcs 5	A-K16 16A 1 Gang Retractive Switch PACK: 100pcs 6	A30-K19 10AX 1 Gang Intermediate Switch PACK: 100pcs 7	A30-K20 10AX 2 Gang Intermediate Switch PACK: 100pcs 8	A30-C22-2 16A 2P+E French Socket PACK: 100pcs 25	A30-C23-2 16A 2P European Socket PACK: 100pcs 26	A30-C17-2 15A 3 Round Pin Socket with Switch PACK: 100pcs 27	A30-C38 15A 3 Round Pin Switched Socket with LED Indicator PACK: 100pcs 28
							
A30-P01 Single Blank Plate PACK: 200pcs 9	A30-K45 A30-K46 5A / 13A Fuse Switch PACK: 100pcs 10	A30-K30 20A Double Pole Switch with Neon PACK: 100pcs 11	A30-K50-2 45A Double Pole Switch with LED Indicator PACK: 100pcs 12	A30-C06 16A 2 Pin & 3 Pin Universal Socket PACK: 100pcs 29	A30-C36 16A 3 Pin Universal Socket with Switch PACK: 100pcs 30	A30-C37 16A 3 Pin Universal Switched Socket with LED Indicator PACK: 100pcs 31	A38-C45 16A Switched Universal Socket with Night Light PACK: 80pcs 32
							
A30-C11-2 13A BS Socket PACK: 100pcs 13	A30-C29-3 13A Single Switch Socket PACK: 100pcs 14	A30-C12-3 13A Single Switch Socket with Neon PACK: 100pcs 15	A30-C31-2 13A BS Socket with DP Switch PACK: 100pcs 16	A30-C06E29 2 Pin & 3 Pin Universal Socket with 2.1A Double USB Charger PACK: 80pcs 33	A30-C06E24 16A 2 Pin & 3 Pin Universal Socket with 3.4A Double USB Charger PACK: 80pcs 34	A30-C06E32 2 Pin & 3 Pin Universal Socket with Type A+C USB Charger PACK: 80pcs 35	A30-E24-2 3.1A Double USB Charger PACK: 80pcs 36
							
A30-C32-2 13A BS Socket with DP Switch & LED Indicator PACK: 100pcs 17	A30-C29E16 13A BS Switched Socket with 2.1A USB Charger PACK: 80pcs 18	A30-C31E16 13A Double Pole BS Switched Socket with 2.1A USB Charger PACK: 80pcs 19	A30-JAC28 A30-JBC28 16A 2 Pin Universal Socket with Switch PACK: 100pcs 20	A30-E31 20W Type A+C USB Charger PACK: 80pcs 37	A30-E33 65W Type A+C USB Charger PACK: 80pcs 38	A30-P37 45A Flex Outlet PACK: 80pcs 39	A30-P38 25A Flex Outlet PACK: 100pcs 40



A30-E01
Single Telephone Socket

PACK: 100pcs 41




A30-E02
Single Computer Socket

PACK: 100pcs 42



A30-E03
Single TV Socket

PACK: 100pcs 43



A30-2E01
Double Telephone Socket

PACK: 100pcs 44



A30-K93
100W Step Fan Dimmer Switch

PACK: 60pcs 61



A30-K12
Air Control Dimmer Switch

PACK: 80pcs 62




A30-K01BK09
300W Light Dimmer With Two Way Rocker Switch

PACK: 80pcs 63



A30-K01BK11
300W Fan Dimmer With Two Way Rocker Switch

PACK: 80pcs 64



A30-2E02
Double Computer Socket (CAT.6)

PACK: 100pcs 45



A30-E0102
Telephone & Computer Socket (CAT.6)

PACK: 100pcs 46



A30-2E03
Double TV Socket

PACK: 100pcs 47



A30-E06
Single Satellite Socket

PACK: 100pcs 48



A30-K25
65-100W Voice Activated & Light Sensor Switch with Time Delay

PACK: 100pcs 65



A30-K26
65-100W Touch Switch with Time Delay

PACK: 100pcs 66



A30-K23
65-100W PIR Switch

PACK: 80pcs 67



A30-K85
PIR Foot Light

PACK: 100pcs 68




A30-E0608
TV & Satellite Socket

PACK: 100pcs 49



A30-E0103
Telephone & TV Socket

PACK: 100pcs 50



A30-E0203
Computer & TV Socket (CAT.6)

PACK: 100pcs 51



A30-E0206
Computer & Satellite Socket (CAT.6)

PACK: 100pcs 52




A30-K36
LED Foot Light

PACK: 80pcs 69



A30-K37
1W Buzzer

PACK: 100pcs 70



A30-K31
3A Alarm Switch

PACK: 100pcs 71



A30-K17
4A Bell Switch with "DO NOT DISTURB" Indicator

PACK: 100pcs 72



A30-2E07
2 Gang Speaker Outlet

PACK: 100pcs 53



A30-K22 A30-K24
Background/General Speaker Voice Dimmer Switch

PACK: 80pcs 54



A30-K09
300W Light Dimmer Switch

PACK: 80pcs 55



A30-K10
630W Light Dimmer Switch

PACK: 80pcs 56



A30-K18
4A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" Indicator

PACK: 100pcs 73



A30-K21
4A Bell Switch with "DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Indicator

PACK: 100pcs 74



A30-K15
16A Key card Switch

PACK: 80pcs 75



A30-K43
16A Low Frequency Key Card Switch

PACK: 80pcs 76



A30-K86
1000W Two Way Push Dimmer Switch

PACK: 60pcs 57



A30-2K100
Twin 100W LED Dimmer Switch

PACK: 80pcs 58



A30-K11
300W Fan Dimmer Switch

PACK: 80pcs 59



A30-K88
300W Two Way Push Fan Dimmer Switch

PACK: 60pcs 60



A30-K44
16A High Frequency Key Card Switch

PACK: 80pcs 77



A30-K96
"DO NOT DISTURB" Switch

PACK: 100pcs 78



A30-K97
"DO NOT DISTURB" & "MAKE UP ROOM" Switch

PACK: 100pcs 79



A30-K98
"DO NOT DISTURB" & "MAKE UP ROOM" & "PLEASE WAIT" Switch

PACK: 100pcs 80




A30-C34
10VA 115V~ / 10A 230V~
Shaver Socket
PACK:16 pcs 81



A38-C08
Shaver Socket
PACK: 10pcs 82



A38-C13
13A Twin BS Socket
PACK: 70pcs 83



A38-C30
13A Twin Switched Socket
PACK: 70pcs 84



A38-C14
13A Twin Socket with switch
& LED Indicator
PACK: 70pcs 85



A38-C39
13A DP Twin Switched Socket
PACK: 70pcs 86



A38-C40
13A DP Twin Socket with switch
& LED Indicator
PACK: 70pcs 87



A38-C30E24
13A Twin Switched Socket with
2 Ports USB Charger
PACK: 40pcs 88




A38-C14E24
13A Twin Switched Socket with
2 Ports USB Charger & Neon
PACK: 40pcs 89



A38-C39E24
13A Twin DP Switched Socket
with 2 Ports USB Charger
PACK: 40pcs 90



A38-C40E24
13A Twin DP Switched Socket
with 2 Ports USB Charger & Neon
PACK: 40pcs 91



A38-C43
16A Twin Universal Switched
Socket
PACK: 60pcs 92



A38-C43E24
16A Twin Universal Switched Socket
with 2 Ports USB Charger
PACK: 40pcs 93



A38-C44
16A Twin Universal Switched Socket
with Neon
PACK: 60pcs 94



A38-C44E24
16A Twin Universal Switched Socket
with 2 Ports USB Charger & Neon
PACK: 40pcs 95



A38-C26
45A Cooker Unit
PACK: 60pcs 96



A38-K90
147 45A DP Switch
PACK: 60pcs 97



A38-P28
Double Blank
PACK: 140pcs 98

Accessories



A30-P02
Water Proof
PACK:39 pcs 1



86-P15
Mounting Box
PACK:240 pcs 2



A77-P30
IP56 Water Proof Box
PACK: 50pcs 3



BS-P14-25
0.8mm 3X3 BS Metal wall
mounting box 25mm depth
PACK: 100pcs 4



BS-P14-35
0.8mm 3X3 BS Metal wall
mounting box 35mm depth
PACK: 100pcs 5



BS-P14-47
0.8mm 3X3 BS Metal wall
mounting box 47mm depth
PACK: 100pcs 6



BS-2P14-25
0.8mm 3X6 BS Metal wall
mounting box 25mm depth
PACK: 100pcs 7



BS-2P14-35
0.8mm 3X6 BS Metal wall
mounting box 35mm depth
PACK: 100pcs 8



BS-2P14-47
0.8mm 3X6 BS Metal wall
mounting box 47mm depth
PACK: 100pcs 9



YWMD-BX-C06
2&3 Pin Universal Floor
Socket (SS)
PACK: 10pcs 10



YWMD-BX-2C06
Double 3 Pin Universal Floor
Socket (SS)
PACK: 10pcs 11



YWMD-BX-C06E16
3 Pin Universal with USB Floor
Socket (SS)
PACK: 10pcs 12



YWMD-BX-E0116
Telephone with USB Floor
Socket (SS)
PACK: 10pcs 13



YWMD-BX-E0203
Computer with TV Floor
Socket (SS)
PACK: 10pcs 14



YWMD-BX-E01C06
3 Pin Universal with Telephone
Floor Socket (SS)
PACK: 10pcs 15



YWMD-FT-C06
2&3 Pin Universal Floor
Socket (GD)
PACK: 10pcs 16



YWMD-FT-C02E0222
2 Pin with Computer with
HDMI Floor Socket (GD)
PACK: 10pcs 17

Mini Circuit Breaker / Residual Current Circuit Breaker



JDM60-1P
1P Mini Circuit Breaker
10A-63A
PACK: 240pcs 18



JDM60-2P
2P Mini Circuit Breaker
10A-63A
PACK: 120pcs 19



JDM60-3P
3P Mini Circuit Breaker
10A-63A
PACK: 80pcs 20



JDM60-4P
4P Mini Circuit Breaker
10A-63A
PACK: 60pcs 21



JDMR60-1P+N
1P+N Residual Current Circuit
Breaker 10A-63A
PACK: 80-100pcs 22



JDMR60-2P
2P Residual Current Circuit
Breaker 10A-63A
PACK: 60pcs 23



JDMR60-3P+N
3P+N Residual Current Circuit
Breaker 10A-63A
PACK: 40pcs 24



JDMR-4P
4P Residual Current Circuit
Breaker 10A-63A
PACK: 20-40pcs 25